


# EMCO WinNC GE Series Fanuc 0-MC

Software description/ Software version from 13.76



## Software description

**EMCO WinNC Fanuc 0-MC**

**Ref.No. EN 1801 Edition I2003-7**

EMCO Maier Ges.m.b.H.

P.O. Box 131

A-5400 Hallein-Taxach/Austria

Phone ++43-(0)62 45-891-0

Fax ++43-(0)62 45-869 65

Internet: [www.emco.at](http://www.emco.at)

E-Mail: [service@emco.co.at](mailto:service@emco.co.at)

**emco**

innovative machine tools  
industrial training systems

## Preface

The software EMCO WinNC FANUC SERIES 0-MC Milling is a part of the EMCO education concept on PC basis.

Target of this concept is learning to operate and program the original control at the PC.

The milling machines of the EMCO PC MILL und CONCEPT MILL series can be directly controlled via PC by means of the EMCO WinNC for the EMCO MILL.

The operation is rendered very easy by the use of a digitizer or the control keyboard with TFT flat panel display (optional accessory), and it is didactically especially valuable since it remains very close to the original control.

This manual does not include the whole functionality of the control software FANUC SERIES 0-MC Milling, however emphasis was laid on the simple and clear illustration of the most important functions so as to achieve a most comprehensive learning success.

In case any questions or proposals for improving this manual should arise, please contact us directly:

EMCO MAIER Gesellschaft m. b. H.  
Department Technical Documentation  
A-5400 Hallein, Austria

# Contents

## A: Key Description

Control Keyboard, Digitizer Overlay .....	A5
Key Functions .....	A5
Data Input Keys .....	A6
Function Keys .....	A6
Machine Control Keys .....	A8
PC Keyboard .....	A10

## B: Basics

Reference Points of the EMCO Milling Machines .....	B11
Zero Offset .....	B12
The Coordinate System .....	B12
Input of the Zero Offset .....	B13
Tool Data Measuring .....	B14
Tool Data Measuring by Scraping .....	B15

## C: Operating Sequences

Survey Operating Modes .....	C17
Approach the Reference Point .....	C18
Setting of Language and Workpiece Directory .....	C18
Program Input .....	C19
Call Up a Program .....	C19
Input of a block .....	C19
Insert a Word .....	C19
Alter a Word .....	C19
Delete a Word .....	C19
Search a Word .....	C19
Insert a Block .....	C19
Delete a Block .....	C19
Delete a Program .....	C20
Delete All Programs .....	C20
Data Input - Output .....	C20
Adjusting the Serial Interface .....	C20
Program Output .....	C21
Program Input .....	C21
Tool Offset Output .....	C21
Tool Offset Input .....	C21
Print Programs .....	C21
Program Run .....	C22
Start of a Part Program .....	C22
Displays while Program Run .....	C22
Block Search .....	C22
Program Influence .....	C22
Program interruption .....	C22
Display of the Software Versions .....	C22
Part Counter and Piece Time .....	C23
Graphic Simulation .....	C24

## D: Programming

Program Structure .....	D25
Used Addresses .....	D25
Command survey M-functions .....	D25
Survey of G Commands for	
Command Definition C .....	D26
Description of G Commands .....	D27
G00 Positioning (Rapid Traverse) .....	D27
G01 Linear Interpolation .....	D27
G02 Circular Interpolation Clockwise .....	D29
G03 Circular Interpolation Counterclockwise .....	D29
Helix Interpolation .....	D29
G04 Dwell .....	D30
G09 Exact Stop .....	D30
G10 Data Setting .....	D31
G15 End Polar Coordinate Interpolation .....	D32
G16 Begin Polar Coordinate Interpolation .....	D32
G17-G19 Plane Selection .....	D33
G20 Measuring in Inches .....	D33
G21 Measuring in Millimeter .....	D33
G28 Approach Reference Point .....	D34
G33 Thread Cutting .....	D34
Cutter Radius Compensation .....	D35
G40 Cancel Cutter Radius Compensation .....	D35
G41 Cutter Radius Compensation left .....	D35
G42 Cutter Radius Compensation right .....	D35
G43 Tool Length Compensation positive .....	D37
G44 Tool Length Compensation negative .....	D37
G49 Cancel Tool Length Compensation .....	D37
G50 Cancel Scale Factor, Mirror .....	D37
G51 Scale Factor, Mirror .....	D37
G52 Local Coordinate System .....	D39
G53 Machine Coordinate System .....	D39
G54 - G59 Zero Offsets 1 - 6 .....	D39
G61 Exact Stop Mode .....	D40
G62 Automatic Corner Override .....	D40
G64 Cutting mode .....	D40
G68 / G69 Coordinate System Rotation .....	D41
Drilling Cycles G73 - G89 .....	D42
Systematic G98/G99 .....	D42
Number of repetitions .....	D42
G73 Chip Break Drilling Cycle .....	D43
G74 Left Tapping Cycle .....	D43
G76 Fine Drilling Cycle .....	D44
G80 Cancel Drilling Cycles .....	D44
G81 Drilling Cycle .....	D44
G82 Drilling Cycle with Dwell .....	D45
G83 Withdrawal Drilling Cycle .....	D45
G84 Tapping Cycle .....	D46
G85 Reaming Cycle .....	D47
G86 Drilling Cycle with Spindle Stop .....	D47
G87 Back Pocket Drilling Cycle .....	D48
G88 Drilling Cycle with Program Stop .....	D48
G89 Reaming Cycle with Dwell .....	D49
G90 Absolute Programming .....	D49
G91 Incremental Programming .....	D49
G92 Coordinate System Setting .....	D49
G94 Feed per Minute .....	D49
G95 Feed per Revolution .....	D49
G97 Revolutions per Minute .....	D49

G98 Retraction to the Start Plane .....	D49
G98 Retraction to the Withdrawal Plane .....	D49
Description of M Commands .....	D51
M00 Programmed Stop .....	D51
M01 Programmed Stop, Conditional .....	D51
M02 Main Program End .....	D51
M03 Milling Spindle ON Clockwise .....	D51
M04 Milling Spindle ON Counterclockwise .....	D51
M05 Milling Spindle OFF .....	D51
M06 Tool Change .....	D51
M08 Coolant ON .....	D51
M09 Coolant OFF .....	D51
M27 Swivel Dividing Head .....	D51
M30 Main Program End .....	D51
M71 Puff blowing ON .....	D51
M72 Puff blowing OFF .....	D51
M98 Subprogram Call .....	D52
M99 Subprogram End, Jump Instruction .....	D52

## Starting Information

see attachment

## G: Flexible NC programming

Variables and arithmetic parameters .....	G1
Calculating with variables .....	G1
Control structures .....	G2
Relational operators .....	G2

## H: Alarms and Messages


Input Device Alarms 3000 - 3999 .....	H2
Machine Alarms 6000 - 7999 .....	H3
AC95 ALARMS .....	H11
Axis Controller Alarms 8000 - 9999 .....	H11

## I: Control Alarms

Control Alarms .....	I15
----------------------	-----

# A: Key Description


## Control Keyboard, Digitizer Overlay



### Key Functions

RESET ..... Cancel an alarm, reset the CNC (e.g. interrupt a program), etc.  
 CURSOR..... Search function, line up/down  
 PAGE ..... Page up/down  
 ALTER..... Alter word (replace)  
 INSRT ..... Insert word, create new program  
 DELET..... Delete (program, block, word)  
 /,# EOB..... Skip block, **End Of Block**  
 CAN ..... Delete input  
 INPUT ..... Word input, data input  
 OUTPT START .... Start data output

POS..... Indicates the current position  
 PRGRM ..... Edit and display of the program, Input of the MDI data; Display of the command values in the automatic mode  
 MENU OFSET ..... Setting and display of offset values, tool and wear data, variables  
 DGNOS PARAM .. Setting and display of parameter and display of diagnostic data  
 OPR ALARM ..... Alarm and message display  
 AUX GRAPH ..... Graphic display




Data input keys

## Data Input Keys

### Note for the Data Input Keys

Each data input key runs several functions (numbers, address character(s)). Repeated pressing of the key switches to the next function automatically.



Function keys

## Function Keys


### Note for Function Keys

With the PC keyboard the function keys can be displayed as softkeys by pressing the key F12.




### Machine Control Keys











The machine control keys are in the lower block of the control keyboard resp. the digitizer overlay. Depending on the used machine and the used accessories not all functions may be active.




Machine control keyboard





Machine control keyboard of the EMCO PC- Mill Serie

-  SKIP (skip blocks will not be executed)
-  DRY RUN (test run of programs)
-  OPT STOP (program stop at M01)
-  RESET
-  Single block machining
-  Program stop / program start
-  manual axis movement
-  Approaching the reference point in all axes
-  Feed stop / feed start
-  Spindle override lower / 100% / higher





Spindel stop / spindle start; spindle start in JOG and INC1...INC10000 mode:

Clockwise: press  key short, Counterclockwise: press  min. 1 sec.



Open / close door



Swivel dividing head




Open / close clamping device




Swivel tool turret




Coolant on/off




AUX OFF / AUX ON (auxiliary drives off / on)




Vorschub- / Eilgangkorrekturschalter



Feed / rapid feed override switch



EMERGENCY OFF (Unlock: pull out button)



Key switch for special operations (siehe Maschinenbeschreibung)



Additional NC start key



Additional key clamping device




Consent key



No function

PC Keyboard



\$ 4 = 4    \$ 4 = \$    Strg    \$ 4 = = INC 1 000    Alt    \$ 4 = INC 1 000

Some alarms will be acknowledged with the key ESC.  
 By pressing the key F1 the modes (MEM, EDIT, MDI,...) will be displayed in the softkey line.  
 The assignment of the accessory functions is described in the chapter "Accessory Functions".

\* With F12 the function keys POS, PROG, OFFSET SAETTING, SYSTEM, MESSAGES and GRAPH will be displayed in the softkey line.

The machine functions in the numeric key block are active only with active NUM lock.

The meaning of the key combination ctrl 2 depends on the machine:  
 EMCO PC MILL 50/55: Puff blowing ON/OFF  
 EMCO PC MILL 100/125/155: coolant ON/OFF



## B: Basics

### Reference Points of the EMCO Milling Machines

#### **M = Machine zero point**

An unchangeable reference point established by the machine manufacturer.

Proceeding from this point the entire machine is measured.

At the same time "M" is the origin of the coordinate system.

#### **R = Reference point**

A position in the machine working area which is determined exactly by limit switches. The slide positions are reported to the control by the slides approaching the "R".


Required after every power failure.

#### **N = Tool mount reference point**


Starting point for the measurement of the tools. "N" lies at a suitable point on the tool holder system and is established by the machine manufacturer.

#### **W = Workpiece zero point**

Starting point for the dimensions in the part program. Can be freely established by the programmer and moved as desired within the part program.



Reference points in the working area



Zero offset from machine zero (M) to workpiece zero point (W)

## Zero Offset


With EMCO milling machines the machine zero "M" lies at the left front edge of the machine table. This position is unsuitable as a starting point for dimensioning. With the so-called zero offset the coordinate system can be moved to a suitable point in the working area of the machine.

The offset register (WORK) offers seven adjustable zero offsets.

When you define a value in the offset register, this value will be considered with call in program (with G54 - G59) and the coordinate zero point will be shifted from the machine zero M to the workpiece zero W.

The workpiece zero point can be shifted within a program in any number.

More informations see in command description.



Absolute coordinates refer to a fixed point, incremental coordinates to the tool position

## The Coordinate System

### Coordinate system for absolute value programming

The origin of the coordinate system lies at the machine zero "M" or at the workpiece zero "W" following a programmed zero offset.


The X coordinate lies parallel to the machine table front edge, the Y coordinate parallel to the side edge and the Z coordinate vertical to the machine table. Z Coordinate values in minus directions describe movements of the tool system towards the workpiece. Values in plus direction away from the workpiece, All target points are described from the origin of the coordinate system by the indication of the respective X, Y and Z distances.

### Coordinate system for incremental value programming

The origin of the coordinate system lies at the tool mount reference point "N" or at the cutting tip after tool length compensation.






Coordinate directions in plus and minus direction like with absolute programming. The plus and minus directions are the same as for absolute value programming.


With incremental value programming the actual paths of the tool (from point to point) are described.




Input pattern for zero offsets

## Input of the Zero Offset

- Press the key 
- Select the softkey WORK
- The input pattern beside will be displayed
- You can enter the following offsets:  
 00 .... basic offset                      02 ..... G55  
 01 .... G54                                      03 ..... G56  
 The basic offset is always active, other offsets will be added to.
- By pressing the key  you get the next display page. Here you can enter the following offsets:  
 04 .... G57                                      06 ..... G59  
 05 .... G58
- Below X, Y, Z you can enter the distance **from the machine zero point to the workpiece zero point (pos. sign)**.
- Go with the cursor to the desired offset with the keys  and .
- Enter the desired offset (e.g.: X+30.5) and press the key 
- Enter the desired offset values one by one.



Length correction



Cutter radius R

## Tool Data Measuring

Aim of the tool data measuring:

The CNC should use the tool tip resp. the tool centre at the face end for positioning, not the tool mount reference point.

Every tool which is used for machining has to be measured. The distance between tool tip and tool mount reference point is to be measured.

To every of this distances a correction number in the offset register (OFFSET) is related to.

The correction number can be any register number, but has to be considered with tool call in program.

The length corrections can be measured half-automatically, the **cutter radius** has to be inserted manually.

Inserting the cutter radius is **only** necessary for using **cutter radius compensation** with this tool.

For G17 (XY plane active):

Tool data measuring occurs for








Z absolute from point "N"

R radius of the cutter

For all other active planes always the vertical axis to the plane is computed. In the following the normal case G17 is described.

## Tool Data Measuring by Scraping

### Procedure

- Clamp a workpiece in the working area. The measuring point has to be reachable with the tool mount reference point and with all tools to be measured.  
The tool mount reference point of the EMCO PC MILL 100 is on the reference tool (clamp before).
- Select the JOG mode
- Place a thin sheet of paper between work piece and milling spindle.
- Traverse with the tool mount reference point on the workpiece (standing spindle)  
Reduce feed to 1%  
Traverse with the spindle (tool mount reference point) down to the workpiece, so far that the paper still can be moved.
- Press the key  and the softkey REL to show the relative position at the screen.
- Press the key  - the Z display flashes
- Reset Z value with  to 0
- Clamp tool to be measured
- Change to MDI mode
- Switch on the spindle (e.g. S1000 M3 NC-Start)
- Change to JOG mode
- Press the key 
- Scrap on the workpiece
- Now the screen shows the length difference between tool mount reference point and the tool tip (Z value relative)
- Select the corresponding parameter H in the offset register with the keys  
- Key in the displayed Z value as parameter H in the offset register and take it over with the  key.
- Clamp next tool and scrap onto the workpiece surface etc.





## C: Operating Sequences

### Survey Operating Modes

#### ZRN

In this operating mode the reference point will be approached.

With reaching the reference point the actual position display is set to the value of the reference point coordinates. By that the control acknowledges the position of the slides in the working area.

With the following situations the reference point has to be approached::

- After switching on the machine
- After mains interruption
- After alarm "Approach reference point" or "Ref. point not reached"
- After collisions or if the slides stuck because of overload

#### AUTO

For working off a part program the control calls up block after block and interprets them.

The interpretation considers all correction which are called up by the program.

The so-handled blocks will be worked off one by one.

#### EDIT

In the EDIT mode you can enter part programs and transmit data.

#### MDI

In the MDI mode you can switch on the spindle and swivel the tool holder.

The control works off the entered block and deletes the intermediate store for new inputs..

#### JOG

With the JOG keys the slides can be traversed manually.

#### S1 ... S1000 ... 10000

In this operation mode the slides can be traversed for the desired increment (1...10000 in  $\mu\text{m}/10^{-4}$  inch) by

means of the JOG keys    

#### 

The selected increment (1, 10, 100, ...) must be larger than the machine resolution (lowest possible traverse movement), otherwise no movement occurs.

#### REPOS

Repositioning, approach back to the contour in JOG mode.

#### Teach In

Making programs in dialogue with the machine in MDA mode.

## Approach the Reference Point

By approaching the reference point the control will be synchronized to the machine.


- Change into ZRN mode
- Press as first the direction keys **-Z** or **+Z**, then **-X** or **+X** and **-Y** or **+Y** to approach the reference point in the respective direction.
- With the key **REF ALL** all axes will be approached automatically in the correct sequence (PC keyboard).

### Danger of Collisions

Mind for obstacles in the working area (Clamping devices, clamped work pieces, etc.)

After reaching the reference point its position will be displayed as actual position. Now the machine is synchronized to the control.

## Setting of Language and Workpiece Directory

- Press the key **DGNOS PARAM**.
- Press the key **PAGE**  multiple, until the setting page (GENERAL) will be displayed.

### Workpiece Directory

In the workpiece directory the CNC programs created by the operator will be stored. The workpiece directory is a subdirectory of the program directory which was determined with installation.

Enter in the input field "PATH = ..." the name of the workpiece directory with the PC keyboard, max. 8 characters, no drives or pathes. Not existing directories will be created.

### Active Language

Selection from installed languages, the selected language will be activated with restart of the software.




Enter the language sign in the input field "LANG = ..."

- DT for German
- EN for English
- FR for French
- SP for Spanish

## Program Input


Part programs and subprograms can be entered in the EDIT mode.

### Call Up a Program

- Change into EDIT mode
- Press the key 
- With the softkey LIB the existing programs will be displayed.
- Enter program number O...
- New program: Press the key 
- Existing program: Press the key 

### Input of a block

Example:




Block number (not necessary)

1. word

2. word


EOB - End of block (on PC keyboard also




Note:

With the parameter "SEQ" (SETTING 1) you can determine whether block numbering should occur automatically (1 = yes, 0 = no).


### Insert a Word

Move the cursor before the word, that should be before the inserted word, enter the new word (address and value) and press the key .

### Alter a Word


Move the cursor before the word that should be altered, enter the word and press the key .

### Delete a Word

Move the cursor before the word, that should be deleted and press the key .

### Search a Word

Enter the address of the word to be searched (e.g.:


X) and press the key .

### Insert a Block


Move the cursor before the EOB sign ";" in that block which should be before the inserted block and enter the block to be inserted.

### Delete a Block


Enter block number (if no block number exists: N0)


and press the key .

### Delete a Program


EDIT mode  
 Enter the program number (e.g.: O22) and press the key .

### Delete All Programs

EDIT mode  
 Enter the program number O 0-9999 and press the key .



Selection of the input/output interface




Adjusting the serial interface



**NOTE**

When you use an interface expansion card (e.g. for COM 3 and COM 4), take care that for every interface a separate interrupt is used (e.g.: COM1 - IRQ4, COM2 - IRQ3, COM3 - IRQ11, COM4 - IRQ10).



### Data Input - Output

- Press the key . The screen shows (SETTING 1).
- Below "I/O" you can enter a serial interface (1 or 2) or a drive (A, B or C).
  - 1 serial interface COM1
  - 2 serial interface COM2
  - A disk drive A
  - B disk drive B
  - C hard disk drive C, workpiece directory (Established with installation or in (GENERAL)).
  - P Printer on LPT1.



### Adjusting the Serial Interface

- Press the key .
  - Press the key , until (PARAMETERS OF SERIAL INTERFACE) is displayed.
- Settings:
- Baudrate 110, 150, 300, 600, 1200, 2400, 4800, 9600
- Parity E, O, N
- Stopbits 1, 2
- Datenbits 7, 8
- Data transmission from / to original control in ISO-Code only
- ISO: 7 Datenbits, Parity even (=E)
- Control parameter:
- Bit 0: 1...Transmission will be cancelled with ETX (End of Text) code
- 0...Transmission will be cancelled with RESET
- Bit 7: 1...Overwrite part program without message
- 0...Message, if a program already exists
- ETX code: % (25H)



### Program Output

- EDIT mode
- Enter the receiver in (SETTING 1) below "I/O".
- Press the key .
- Enter the program to be sent (e.g. O22)
- When you enter e.g. O5-15, all programs with the numbers 5 to inclusive 15 will be transmitted. When you enter O-9999 as program number, all programs will be transmitted.
- Press the key .



### Program Input

- EDIT mode
- Enter the receiver in (SETTING 1) below "I/O".
- Press the key .
- With input from disk or hard disk you have to enter a program number.  
Enter the program number when you want to read in one program (e.g.: O22).  
When you enter e.g. O5-15, all programs with the numbers 5 to inclusive 15 will be transmitted. When you enter O-9999 as program number, all programs will be transmitted.
- Press the key .



### Tool Offset Output

- EDIT mode
- Enter the receiver in (SETTING 1) below "I/O".
- Press the keys  and .
- If a drive (A, B or C) is the receiver, the zero offsets will be transmitted additionally.

### Tool Offset Input

- EDIT mode
- Enter the sender in (SETTING 1) below "I/O".
- Press the keys  and .




### Print Programs

- The printer has to be connected to LPT1 and must be in ON LINE status.
- EDIT mode
- Enter P (printer) in (SETTING 1) below "I/O".
- Press the key .
- Enter the program to be print (e.g. O22)
- When you enter e.g. O5-15, all programs with the numbers 5 to inclusive 15 will be printed. When you enter O-9999 as program number, all programs will be printed.
- Press the key .

## Program Run


### Start of a Part Program

Before starting a program the control and the machine must be ready for running the program.

- Select the EDIT mode.
- Press the key .
- Enter the desired part program number (e.g.: O79).
- Press the key .
- Change to AUTOMATIC mode.
- Press the key .

### Displays while Program Run




While program run different values can be shown.

- Press the softkey PRGRM (basic status). While program run the actual program block will be displayed.
- Press the softkey CHECK. While program run the actual program block, the actual positions, active G and M commands and speed, feed and tool will be displayed.
- Press the key . The positions will be shown enlarged at the screen.

### Block Search

With this function you can start a program at any block.

While block search the same calculations will be proceeded as with normal program run but the slides do not move.

- EDIT mode
- Select the program to be machined.
- Move the cursor with the keys  and  on that block, with which machining should start.
- Change to AUTOMATIC mode.
- Start the program with the key .

### Program Influence

#### DRY RUN

DRY RUN is used for testing programs. The main spindle will not be switched on and all movements occur in rapid feed.

If DRYRUN is active, DRY will be displayed in the first line on the screen.

#### SKIP

With SKIP all program blocks which are marked with a "/" (e.g.: /N0120 G00 X...) will not be proceeded and the program will be continued with the next block without a "/" sign.

If SKIP is active, SKP will be displayed in the first line on the screen.

### Program interruption

#### Single block mode

After every program block the program will be stopped.

Continue the program with the key .

#### M00


After M00 (programmed stop) in the program the program will be stopped. Continue the program with


the key .

#### M01

If OPT. STOP is active, (display OPT in the first line of the screen) M01 works like M00, otherwise M01 has no effect.

### Display of the Software Versions

- Press the key .
  - Select softkey DGNOS
- The software version of the control system and the eventually connected RS485 devices will be displayed.



Display of part counter and piece time

## Part Counter and Piece Time



Below the position display the part counter and the piece time are displayed.

The part counter shows the number of program runs. Each M30 (or M02) increases the part counter for 1.



RUN TIME shows the complete running time of all program runs.


CYCLE TIME shows the running time of the actual program and will be reset to 0 with every program start.

### Part Counter Reset

The part counter will be reset to 0 by pressing  (P) and  after.

### RUN TIME Reset

The RUN TIME (total time) will be reset to 0 by pressing  (R) and  after.



Presetting the piece counter

### Preset of the Part Counter

The part counter can be preset in (SETTING 2). Therefore move the cursor on the desired value and enter the new value.

#### PART TOTAL:

Each M30 increases this number by 1. Every program run of every program will be counted (= number of all program runs).


#### PART REQUIRED:

Preset part number. When this number is reached the program will be stopped and message 7043 PIECE COUNT REACHED will be displayed.

After that the program can be started only after resetting the part counter or increasing the preset part number.


## Graphic Simulation

NC-programs can be simulated graphically.

Press the key .

The screen shows the input pattern for graphic simulation.

The simulation area is a rectangular window, which is determined by the right upper and left lower edge.



Input pattern for graphic simulation

### Inputs:

#### AXIS P

Enter the simulation plane here.

- 0 XY plane
- 1 XZ plane
- 2 YZ plane

#### MAXIMUM/MINIMUM


Enter here the right upper (X, Y, Z) and the left lower (I, J, K) edge of the simulation area.

All other inputs and the softkeys SOLID and AUX are not active.

After pressing the key  the softkey 3DVIEW will be shown.


Win 3D View is an option and not included in the basic version of the software.

With the softkeys path and EXEC you will get into the simulation window.



Simulation window

The softkeys PARA-1, PARA-2, SCALE and POS are not active.

With the key  you will go back to the input pattern for graphic simulation.

With the softkey START the graphic simulation starts.

With the softkey STOP the graphic simulation stops.

With the softkey RESET the graphic simulation will be aborted.

Movements in rapid traverse will be displayed as dashed lines, movements in working traverse will be displayed as full lines.



## D: Programming

### Program Structure

CNC programming for machine tools according to DIN 66025 is used.

The CNC program is a sequence of program blocks which are stored in the control.

With machining of workpieces these blocks will be read and checked by the computer in the programmed order.

The corresponding control signals will be sent to the machine.

The CNC program consists of:

- Program number
- CNC blocks
- Words
- Addresses
- number combinations (for axis addresses partly with sign)

### Command survey M-functions

M00	.....	Programmed stop
M01	.....	Programmed stop conditional
M02	.....	Program end
M03	.....	Spindle ON in clockwise direction
M04	.....	Spindle ON in counter-clockwise direction
M05 <sup>1</sup>	.....	Spindle OFF
M06	.....	Tool change
M07	.....	Minimum lubrication ON
M08	.....	Coolant ON
M09 <sup>1</sup>	.....	Coolant OFF
M10	.....	Clamp round axis
M11	.....	Round axis release clamping
M27	.....	Swivel dividing unit
M30	.....	Program end
M71	.....	Blow-out ON
M72 <sup>1</sup>	.....	Blow-out OFF
M98	.....	Subroutine call
M99	.....	Subroutine end

<sup>1</sup>..... Switch-on state

### Used Addresses

C	.....	chamfer
F	.....	feed rate, thread pitch
G	.....	path function
H	.....	number of the correction value address in the offset register (OFFSET)
I, J, K	....	circle parameter, scale factor, K also number of repetitions of a cycle, mirror axes
M	.....	miscellaneous function
N	.....	block number 1 to 9999
O	.....	Program number 1 to 9499
P	.....	dwel, subprogram call
Q	.....	cutting depth or shift value in cycle
R	.....	radius, retraction height with cycle
S	.....	spindle speed
T	.....	tool call
X, Y, Z	..	position data (X also dwel)
;	.....	block end

## Survey of G Commands

G00 <sup>1</sup>	Positioning (Rapid Traverse)
G01	Linear Interpolation
G02	Circular Interpolation Clockwise
G03	Circular Interpolation Counterclockwise
G04 <sup>2</sup>	Dwell
G09 <sup>2</sup>	Exact Stop
G10	Data Setting
G11	Data Setting Off
G15 <sup>1</sup>	End Polar Coordinate Interpolation
G16	Begin Polar Coordinate Interpolation
G17 <sup>1</sup>	Plane Selection XY
G18	Plane Selection ZX
G19	Plane Selection YZ
G20	Measuring in Inches
G21	Measuring in Millimeter
G28 <sup>2</sup>	Approach Reference Point
G33	Thread Cutting
G40 <sup>1</sup>	Cancel Cutter Radius Compensation
G41	Cutter Radius Compensation left
G42	Cutter Radius Compensation right
G43	Tool Length Compensation positive
G44	Tool Length Compensation negative
G49 <sup>1</sup>	Cancel Tool Length Compensation
G50 <sup>1</sup>	Cancel Scale Factor
G51	Scale Factor
G52 <sup>2</sup>	Local Coordinate System
G53 <sup>2</sup>	Machine Coordinate System
G54 <sup>1</sup>	Zero Offset 1
G55	Zero Offset 2
G56	Zero Offset 3
G57	Zero Offset 4
G58	Zero Offset 5
G59	Zero Offset 6
G61	Exact Stop Mode
G62	Automatic Corner Override
G64 <sup>1</sup>	Cutting mode
G68	Coordinate System Rotation ON
G69	Coordinate System Rotation OFF
G73	Chip Break Drilling Cycle
G74	Left Tapping Cycle
G76	Fine Drilling Cycle
G80 <sup>1</sup>	Cancel Drilling Cycles (G83 bis G85)
G81	Drilling Cycle
G82	Drilling Cycle with Dwell
G83	Withdrawal Drilling Cycle
G84	Tapping Cycle
G85	Reaming Cycle
G86	Drilling Cycle with Spindle Stop
G87	Back Pocket Drilling Cycle
G88	Drilling Cycle with Program Stop
G89	Reaming Cycle with Dwell
G90 <sup>1</sup>	Absolute Programming
G91	Incremental Programming
G92 <sup>2</sup>	Coordinate System Setting
G94 <sup>1</sup>	Feed per Minute
G95	Feed per Revolution
G97 <sup>1</sup>	Revolutions per Minute
G98 <sup>1</sup>	Retraction to Starting Plane (Drilling Cycles)
G99	Retraction to Withdrawal Plane Initial status

<sup>2</sup> ..... Blockwise effective

## Survey of G Commands for Command Definition C

Group	Command	Function
0	G04	Dwell
	G09	Exact Stop
	G10	Data Setting
	G11	Data Setting Off
	G28	Approach Reference Point
	G52	Local Coordinate System
	G53	Machine Coordinate System
1	G92	Coordinate System Setting
	G00	Positioning (Rapid Traverse)
	G01	Linear Interpolation
	G02	Circular Interpolation Clockwise
2	G03	Circular Interpolation Counterclockwise
	G33	Thread Cutting
	G17	Plane Selection XY
3	G18	Plane Selection ZX
	G19	Plane Selection YZ
5	G90	Absolute Programming
	G91	Incremental Programming
6	G94	Feed per Minute
	G95	Feed per Revolution
7	G20	Measuring in Inches
	G21	Measuring in Millimeter
8	G40	Cancel Cutter Radius Compensation
	G41	Cutter Radius Compensation left
	G42	Cutter Radius Compensation right
	G43	Tool Length Compensation positive
9	G44	Tool Length Compensation negative
	G49	Cancel Tool Length Compensation
	G73	Chip Break Drilling Cycle
	G74	Left Tapping Cycle
	G76	Fine Drilling Cycle
	G80	Cancel Drilling Cycles
	G81	Drilling Cycle
	G82	Drilling Cycle with Dwell
	G83	Withdrawal Drilling Cycle
	G84	Tapping Cycle
10	G85	Reaming Cycle
	G86	Drilling Cycle with Spindle Stop
	G87	Back Pocket Drilling Cycle
	G88	Drilling Cycle with Program Stop
	G89	Reaming Cycle with Dwell
	G98	Retraction to Starting Plane
	G99	Retraction to Withdrawal Plane
	G50	Cancel Scale Factor
11	G51	Scale Factor
13	G97	Revolutions per Minute
	G54	Zero Offset 1
	G55	Zero Offset 2
	G56	Zero Offset 3
	G57	Zero Offset 4
	G58	Zero Offset 5
	G59	Zero Offset 6
14	G61	Exact Stop Mode
	G62	Automatic Corner Override
	G64	Cutting Mode
15	G68	Coordinate System Rotation ON
	G69	Coordinate System Rotation OFF
16	G15	End Polar Coordinate Interpolation
	G16	Begin Polar Coordinate Interpolation

## Description of G Commands

### G00 Positioning (Rapid Traverse)

**Format**

N... G00 X... Y... Z...

The slides are traversed at maximum speed to the programmed target point (tool change position, start point for a following machining routine)

**Notes**

- A programmed feed F will be suppressed while G00
- The maximum speed is defined by the producer of the machine
- The feed override switch is active


**Example**

**absolute G90**

N50 G00 X40 Y56

**incremental G91**

N50 G00 X-30 Y-30.5



Absolute and incremental measures

### G01 Linear Interpolation

**Format**

N... G01 X... Y... Z.... F....

Straight movements at the programmed feed rate.

**Example**

**absolute G90**


N.. G94

.....  
N20 G01 X40 Y20.1 F500

**incremental G91**

N.. G94 F500

.....  
N20 G01 X20 Y-25.9



Absolute and incremental measures


## Chamfers and Radius

By programming the parameter C or R a chamfer or a radius can be inserted between two G00 or G01 movements.

Format:

N.. G00/G01 X.. Y.. C/R

N.. G00/G01 X.. Y..



Chamfer and radius in a drawing

Programming of chamfers and radii is possible for the active plane only. Following the programming in the XY plane (G17) is described.

The movement which is programmed has to start at point b of the drawing.

With incremental programming the distance from point b must be programmed.


With single block mode the tool starts first at point c and then at point d.

The following situations cause an error message:


- If the traverse path in one of the two G00/G01 blocks is so short, that with inserting a chamfer or a radius no intersection point would be existing, error message no. 055 will appear.
- If in the second block no G00/G01 command is programmed, error message no. 51, 52 will appear.

## G02 Circular Interpolation Clockwise

## G03 Circular Interpolation Counterclockwise



Rotational directions of G02 and G03



Helix curve

### Format

N... G02/G03 X... Y... Z... I... J... K... F...  
or  
N... G02/G03 X... Y... Z... R... F...

X, Y, Z .. End point of the arc (abs. or incr.)

I, J, K.... Incremental circle parameter  
(distance from start point to the centre point, I is related to X, J to Y, K to Z)

R..... Radius of the arc (arc < semicircle with +R,  
> semicircle with -R), can be programmed instead of the circle parameter I, J, K

The tool will be traversed along the defined arc with the programmed feed F.

### Notes

The circular interpolation can be proceeded in the active plane only.

Programming the value 0 for I, J or K can be omitted.

The observation of G02, G03 occurs always vertical to the active plane.

## Helix Interpolation

Normally only two axes will be programmed for a circle. These axes determine also the active plane. If a third vertical axis will be programmed, the movements of the slides will be coupled in a way that a screw line results.

The programmed feed rate will not be hold at the real path, but on the circle path (projected). The third, linear traversed axis will be controlled in a way, that it reaches the end point at the same time as the circular traversed axes.

### Limitations

- A helix interpolation is possible with G17 (XY plane) only.
- The gradient angle  $\phi$  must be less than  $45^\circ$ .
- If the spatial tangents differ more than  $2^\circ$  with block transitions, an exact stop will be proceeded in every case before/after the helix.

## G04 Dwell

### Format

N... G04 X... [sec]

or

N... G04 P... [msec]

The tool movement will be stopped for a time defined by X or P in the last reached position - sharp edges - transitions, cleaning drilling ground, exact stop


### Notes

- With address P no decimal point can be used
- The dwell starts at the moment when the tool movement speed from the last movement becomes zero.
- t max. = 2000 sec
- Input resolution 100 msec (0.1 sec)

### Examples

N75 G04 X2.5 (Dwell = 2.5 sec)

N95 G04 P1000 (Dwell = 1sec = 1000 msec)



## G09 Exact Stop

### Format

N... G09

A block will then be proceeded, when the slides are braked to 0 before. Therefore the edges will not be rounded and precise transitions will result.

G09 is effective blockwise.

## G10 Data Setting

The command G10 allows to overwrite control data, programming parameters, writing tool data etc... G10 is frequently used to program the workpiece zero point.

### Zero point offset

#### Format

N... G10 L2 Pp IP...;

p=0	External workpiece zero point offset
p=1-6	Normal workpiece zero point offset corresponding to the coordinatesystem 1 - 6
IP	Workpiece zero point offset for the several axis. At the programming IP become replaced by the axletters (X,X,Z).


### Tool Compensation

#### Format

N... G10 L11 P...R...;

P	Number of the toll compensation
R	Tool compensation value in the im absolute command- Mode (G90).


At the inkremental value programming (G91) the tool compensation value get add up to the existing value.



Note: By the reason of compatibility with older NC-programms the system allow the input of L1 instead of L11

## G15 End Polar Coordinate Interpolation

## G16 Begin Polar Coordinate Interpolation



*A point determined by polar coordinates*

### Format

N... G15/G16

Between G16 and G15 points can be defined by polar coordinates.

The selection of the plane in which polar coordinates can be programmed occurs with G17 - G19.

With the address of the first axis the radius will be programmed, with the address of the second axis the angle will be programmed, both related to the workpiece zero point.

### Example


N75 G17 G16

N80 G01 X50 Z30

first axis: radius X=50

second axis: angle Y=30





Definition of the main planes

## G17-G19 Plane Selection

### Format

N... G17/G18/G19

With G17 to G19 the plane will be defined, in which circular interpolation and polar coordinate interpolation can be proceeded and in which the cutter radius compensation will be calculated.

In the vertical axis to the active plane the tool length compensation will be proceeded.

G17 XY-Plane

G18 ZX-Plane

G19 YZ-Plane

## G20 Measuring in Inches

### Format

N... G20

By programming G20 the following values will be converted to the inch system:

- Feed F [mm/min, inch/min, mm/rev, inch/rev]
- Offset values (WORK, geometry and wear) [mm, inch]
- Traverse pathes [mm, inch]
- Display of the actual position [mm, inch]
- Cutting speed [m/min, feet/min]

### Notes

- For clearness G20 should be programmed in the first block
- The last active measuring system will be hold - even with main switch off/on.
- To get back to the origin measuring system it is the best to use the MDI mode (e.g. MDI-G20-Cycle Start)

## G21 Measuring in Millimeter

### Format

N... G21

Comments and notes analogous to G20!

## G28 Approach Reference Point

### Format

N... G28 X... Y... Z...

X, Y, Z Coordinates of the intermediate point.

With G28 the reference point will be approached via an intermediate position (X, Y, Z).

First is the movement to X, Y and Z, then the reference point will be approached. Both movements occur with G00!

The shift G92 will be deleted.

## G33 Thread Cutting

Only for PC Mill 100

### Format

N... G33 Z... F...


F ..... Thread pitch [mm]

Z ..... Thread depth


With a fitting tool (boring or facing head) threads can be cut.

### Notes

- Feed and spindle override switch are not active while G33 (100%).
- G33 works only with the EMCO PC Mill 100, because the EMCO PC Mill 50 has no encoder on the milling spindle.



*Application of thread cutting*



Radius compensated tool path

## Cutter Radius Compensation

With the cutter radius compensation the control calculates automatically a path parallel to the programmed contour and compensates so the cutter radius.


### G40 Cancel Cutter Radius Compensation

The cutter radius compensation will be cancelled by G40.

Cancellation is only permitted in combination with a linear traversing movement (G00, G01).

G40 can be programmed in the same block like G00 or G01 or in the previous block.

Usually G40 will be programmed with the retraction to the tool change point.



Definition of G41 cutter radius compensation left

### G41 Cutter Radius Compensation left


If the tool is (viewed in feed direction) at the **left** side of the contour to be worked, G41 has to be programmed.

For calculating a radius, an H parameter in the offset register (OFFSET) which represents the cutter radius must be programmed and called up with G41 e.g.:

N... G41 H..

#### Notes

- Direct change between G41 and G42 is not allowed - previous cancellation with G40.
- Selection in combination with G00 or G01 necessary
- Programming an H parameter is necessary unconditionally, the H parameter is effective modally.




Definition of G42 cutter radius compensation right

### G42 Cutter Radius Compensation right


If the tool is (viewed in feed direction) at the **right** side of the contour to be worked, G42 has to be programmed.

Notes see G41!


**Tool paths with selection / cancellation of the cutter radius compensation**



*Frontal approach or leaving of an edge point*



*Approach or leaving an edge point at side behind*



*Approach or leaving an edge point behind*


— — — programmed tool path  
 ————— real traversed tool path

With arcs always the tangent of the end or start point of the arc will be approached.


The approaching path to the contour and the leaving path from the contour must be larger than the tool radius R, otherwise program interruption with alarm.

If contour elements are smaller than the tool radius R, contour violations could happen. The software computes three blocks forward to recognize this contour violations and interrupt the program with an alarm.


**Tool paths with program run with active cutter radius compensation**



*Tool path at an inner edge*



*Tool path at an outer edge > 90°*



*Tool path at an outer edge < 90°*

— — — programmed tool path  
 ————— real traversed tool path

With arcs always the tangent of the end or start point of the arc will be approached.

If contour elements are smaller than the cutter radius R, contour violations could happen. The software computes three blocks forward to recognize this contour violations and interrupt the program with an alarm.

### G43 Tool Length Compensation positive

### G44 Tool Length Compensation negative

**Format:**

N... G43/G44 H..

With G43 and G44 a value from the offset register (OFFSET) can be called up and added to or subtracted from as tool length. To all following Z movements (with active XY plane - G17) in the program this value will be added to or subtracted from.


**Example:**

N... G43 H05

The value, which is written into the register under H05, will be added to all following Z movements as tool length.

### G49 Cancel Tool Length Compensation

The positive (G43) or negative (G44) shift will be cancelled.



*Enlarging a contour 1:2*

### G50 Cancel Scale Factor, Mirror G51 Scale Factor, Mirror

**Format:**


N... G50

N... G51 X... Y... Z... I... J... K...

With G51 all position data will be calculated in a scale, until the scale will be deselected with G50.

With X, Y and Z a base point  $P_B$  will be defined, from this point all values will be calculated.

With I, J and K for every axis a scale factor (in 1/1000) can be defined.




Distortion of a contour: X 1:2, Y,Z 1:1


If different scale factors will be defined for the axes, the contour will be distorted. Circular movements must not be distorted, otherwise alarm.

### Mirroring a Contour


By programming a negative scale a contour will be mirrored around the base point  $P_B$ .



By programming I-1000 all X positions will be mirrored around the YZ plane.



By programming J-1000 all Y positions will be mirrored around the ZX plane.



By programming K-1000 all Z positions will be mirrored around the XY plane.

## G52 Local Coordinate System

**Format:**

N... G52 X... Y... Z...

With G52 the actual coordinate zero point can be shifted for the values X, Y, Z.

With this function a sub coordinate system to the existing coordinate system can be created.

G52 is effective blockwise, the resulting shift will be holded, until another shift will be activated.

## G53 Machine Coordinate System

**Format:**

N... G53


The machine zero point is determined by the machine manufacturer (EMCO milling machines: at the left front machine table corner).

Certain working sequences (tool change, measuring position...) always will be done at the same position in the working area.

With G53 the zero offset will be cancelled for one program block and the machine coordinate system is active for this block.

## G54 - G59 Zero Offsets 1 - 6

Six positions in the working area can be predetermined as zero points (e.g. points on fix mounted clamping devices). These zero points can be called up with G54 - G59.




## G61 Exact Stop Mode

### Format

N... G61

A block will then be proceeded, when the slides are braked to 0 before. Therefore the edges will not be rounded and precise transitions will result.

G61 is active, until it will be deselected with G62 or G64.



Speed reaction of the slides with G62 and G64

## G62 Automatic Corner Override G64 Cutting mode

### Format

N... G62/64


G62 and G64 have the same effect.

Before reaching the target point in X direction the Y slide will already be accelerated. This causes a steady movement with contour transitions. The contour transition is not exactly sharp-edged (parabola, hyperbola).

The size of the contour transitions is normally within the tolerance of the drawings.



## G68 / G69 Coordinate System Rotation



Coordinate System Rotation G68/ G69

**Format:**

N... G68 a... b... R...

.

N... G69

G68 ..... Coordinate System Rotation ON


G69 ..... Coordinate System Rotation OFF

$\alpha / \beta$  ..... Indicates the coordinates of the rotational center in the respective plane.

R..... Angel of rotation

For example, this function can be used to alter programs by using a rotational command.

The rotation occurs in the actual valid plane (G17, G18 or G19).




Example Coordinate System Rotation

**Example:**

```
N5 G54
N10 G43 T10 H10 M6
N15 S2000 M3 F300
N20 M98 P030100 ;Subprogram call
N25 G0 Z50
N30 M30
```

```
O0100 (Subprogram 0100)
N10 G91 G68 X10 Y10 R22.5
N15 G90 X30 Y10 Z5
N20 G1 Z-2
N25 X45
N30 G0 Z5
N35 M17
```

## Drilling Cycles G73 - G89



Movements with G98 and G99

### Systematic G98/G99

G98 .... After reaching the drilling depth the tool retracts to the start plane

G99 .... After reaching the drilling depth the tool retracts to the withdrawal plane- defined by the R parameter

Is no G98 or G99 active, the tool retracts to the start plane. If G99 (Withdrawal to the withdrawal plane) is programmed the address R must be programmed. With G98 R need not to be programmed.

The computation of the R parameter is different with incremental and absolute programming:

Absolute programming (G90):


R defines the height of the withdrawal plane over the actual workpiece zero point.

Incremental programming (G90):

R defines the height of the withdrawal plane related to the last Z position (start position of the drilling cycle). With a negative value for R the withdrawal plane will be below the start position, with a positive value the withdrawal plane will be over the start position

### Sequence of movements

- 1: The tool traverses with rapid speed from the start position (S) to the plane defined by R (R).
- 2: Cycle-specific drill machining down to end depth (E).
- 3: The withdrawal occurs a: with G98 to the start plane (S) and b: with G99 to the withdrawal plane.




Sequence of movements G98, G99

### Number of repetitions


The K parameter defines the number of repetitions of the cycle.

With absolute programming (G90) it would make no sense to drill several times in the same hole.


With incremental programming (G91) the tool moves on each time for the distances X and Y. This is a simple way of programming rows of borings.



Cycle repetition for a row of holes



Movements of G73 with active G98



Movements of G73 with active G99

### G73 Chip Break Drilling Cycle

**Format**

N... G98(G99) G73/G83 X... Y... Z... (R...) P... Q...  
F... K...

The tool dips into the work piece for the infeed Q, drives back 1 mm to break the chips, dips in again etc. until end depth is reached and retracts with rapid feed.

**Applications**

deep borings, material with bad cutting property

- G98(G99) .. Return to starting plane (withdrawal plane)
- X, Y ..... Hole position
- Z ..... Absolute (incremental) drilling depth
- R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane
- P [msec] .... Dwell at the hole bottom  
P1000 = 1 sec
- F ..... Feed rate
- Q [mm] ..... Cutting division - infeed per cut
- K ..... Number of repetitions

### G74 Left Tapping Cycle

Only for PC Mill 100/125/155.

With this cycle left threads can be produced. The cycle G74 works like G84 but with reversed turning directions.

See Tapping Cycle G84.

### G76 Fine Drilling Cycle

Only for machines with oriented spindle stop.

**Format**

N...G98(G99) G76 X... Y... Z... (R...) F... Q... K...

This cycle is for enlarging borings with boring and facing heads.

The tool traverses with rapid feed to the withdrawal plane, with the programmed feed to the end depth, the milling spindle will be stopped oriented, the tool traverses with rapid speed horizontally (Q) off the surface (against stop direction) and traverses with rapid speed to the withdrawal plane (G99) or start plane (G98) and traverses back for the value Q to the original position.

G98(G99) .. Retraction to start plane (withdrawal plane)

X, Y ..... Hole position


Z ..... Absolute (incremental) drilling depth

R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane

F ..... Feed

Q ..... Horizontal traverse-off value

K ..... Number of repetitions



Movements of G76 - fine drilling cycle

### G80 Cancel Drilling Cycles

**Format**

N... G80

The drilling cycles are modal. They have to be cancelled by G80 or another group 1 command (G00, G01, ...).

### G81 Drilling Cycle

**Format**

N...G98(G99) G81 X... Y... Z... (R...) F... K...

The tool traverses down to end depth with feed speed and retracts with rapid feed.

**Application:**

Short drillings, material with good cutting properties

G98(G99) .. Retraction to start plane (withdrawal plane)


X, Y ..... Hole position

Z ..... Absolute (incremental) drilling depth


R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane

F ..... Feed


K ..... Number of repetitions



Movements of G81 - drilling cycle



Drilling cycle with dwell and retraction to the start plane



Drilling cycle with dwell and retraction to the withdrawal plane

## G82 Drilling Cycle with Dwell

### Format

N... G98(G99) G82 X... Y... Z... (R...) P... F... K...

The tool traverses down to end depth with feed speed, dwells turning to clean the hole ground and retracts with rapid feed.

### Applications

Short borings, material with good cutting property

G98(G99) .. Return to starting plane (withdrawal plane)

X, Y ..... Hole position


Z ..... Absolute (incremental) drilling depth

R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane

P [msec] .... Dwell at the hole bottom  
P1000 = 1 sec

F ..... Feed rate

K ..... Number of repetitions



Movements of G83 with active G98

## G83 Withdrawal Drilling Cycle


### Format

N... G98(G99) G73/G83 X... Y... Z... (R...) P... Q... F... K...

The tool dips into the work piece for the infeed Q, drives back to the start plane (G98) or to the withdrawal plane (G99), to break the chips and remove it from the hole, traverses with rapid speed until 1 mm over the previous drilling depth, dips in again for the infeed Q etc. until end depth is reached and retracts with rapid feed.


### Applications

deep borings, (soft) material with long chips



Movements of G73 with active G99

- G98(G99) .. Return to starting plane (withdrawal plane)
- X, Y ..... Hole position
- Z ..... Absolute (incremental) drilling depth
- R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane
- P [msec] .... Dwell at the hole bottom  
P1000 = 1 sec
- F ..... Feed rate
- Q [mm] ..... Cutting division - infeed per cut
- K ..... Number of repetitions



Tapping cycle (with G99)

### G84 Tapping Cycle

Only for PC Mill 100/125/155.

**Format**


N...G98(G99) G84 X... Y... Z... (R...) F... P... K...

A **tapping chuck with length compensation** must be used.

**Spindle override** and **feed override** will be set fix to **100 %** while machining.

The tool moves turning clockwise with programmed feed into the workpiece down to drilling depth Z, dwells (P), switches to counterclockwise turning and retracts with feed.

- G98(G99) .. Retraction to start plane (withdrawal plane)
- X, Y ..... Hole position
- Z ..... Absolute (incremental) tapping depth
- R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane
- F ..... Thread pitch (feed per revolution)
- P ..... Dwell at thread ground
- K ..... Number of repetitions



Reaming cycle with withdrawal to the start plane

### G85 Reaming Cycle

**Format**

N... G98 (G99) G85 X... Y... Z... (R...) F... K...

The tool traverses down to end depth with feed speed and retracts to the withdrawal plane with feed. Retraction to withdrawal plane with rapid feed depending on G98.

G98(G99) .. Return to starting plane (withdrawal plane)

X, Y ..... Hole position


Z ..... Absolute (incremental) drilling depth

R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane

F ..... Feed rate

K ..... Number of repetitions

### G86 Drilling Cycle with Spindle Stop



Drilling cycle with spindle stop and withdrawal to the start plane

**Format**

N... G98(G99) G86 X... Y... Z... (R...) F...

The tool traverses down to end depth with feed speed. At the hole ground the spindle stops and the tool retracts with rapid feed.

G98(G99) .. Return to starting plane (withdrawal plane)

X, Y ..... Hole position


Z ..... Absolute (incremental) drilling depth

R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane

F ..... Feed rate

K ..... Number of repetitions

### G87 Back Pocket Drilling Cycle



Back pocket drilling cycle

Only for machines with oriented spindle stop

**Format**

N... G87 X... Y... Z... R... Q... F...


Existing drillings can be enlarged in one direction with a boring or facing head.

- The tool will be positioned in X and Y and stopped oriented.
- It will be traversed horizontally for the distance Q against the stop direction of the oriented stop. The value Q must be larger than the tool diameter to avoid collisions.
- The tool traverses to the depth R (no machining).
- The tool traverses back horizontally for the distance Q on the position X, Y (machining).
- The tool traverses vertical to the height Z (machining).
- At height Z the spindle stops oriented, traverses horizontally for the distance Q against the stop direction of the oriented stop (into the existing drilling) and with rapid feed out of the drilling.
- The tool traverses horizontally for the value Q back to the position X,Y.

G99 can not be programmed, the tool always retracts to the start plane.

- X, Y ..... Hole position
- Z ..... Absolute (incremental) drilling depth
- R [mm] ..... Back drilling depth
- F ..... Feed rate

### G88 Drilling Cycle with Program Stop



Drilling cycle with program stop

**Format**

N... G88 X... Y... Z... (R...) P... F... M...

The tool traverses with feed rate to the programmed end depth. At the end depth the program will be stopped after the programmed dwell, retraction occurs manually.

- X, Y ..... Hole position
- Z ..... Absolute (incremental) drilling depth
- R [mm] ..... Absolute (with G91 incremental) value of the withdrawal plane
- P [msec] .... Dwell at end depth:  
P1000 = 1 sec
- F ..... Feed rate



## G89 Reaming Cycle with Dwell

### See G85

The tool traverses with the programmed feed rate to the end depth and dwells (P). Retraction to the withdrawal plane occurs with feed rate, depending on G98 traverses the tool with rapid speed to the start plane.

## G90 Absolute Programming

### Format

N... G90

### Notes

- A direct change between G90 and G91 is allowed also blockwise
- G90 (G91) can be programmed in combination with other G functions.  
(N... G90 G00 X... Y... Z...).

## G91 Incremental Programming

### Format

N... G91

Notes see G90.

## G92 Coordinate System Setting

### Format

N... G92 X... Z... (Coordinate System Setting)

Sometimes it is necessary to shift the zero point within a part program. This occurs with G92.

This zero offset is effective modally and will not be cancelled by M30 or RESET. Therefore it is necessary to activate the previous zero point before program end.

## G94 Feed per Minute

With G94 all F (feed) values are in mm/min.

## G95 Feed per Revolution

Only PC MILL 100

With G95 all F (feed) values are in mm/rev.

## G97 Revolutions per Minute

With G97 all S values are in rev/min.

## G98 Retraction to the Start Plane G98 Retraction to the Withdrawal Plane

see "Drilling Cycles G73 - G89".




## Description of M Commands

### M00 Programmed Stop

This command effects a machining stop within a part program.


The milling spindle, feeds and coolant will be switched off.

The machine door can be opened without releasing an alarm.

With "NC START"  the program run can be continued. After that the main drive will be switched on with all values which were valid before.

### M01 Programmed Stop, Conditional

M01 works like M00, when OPT. STOP is active (display OPT in the first line at the screen). If OPT. STOP is not active, M01 has no effect.

With "NC START"  the program run can be continued. After that the main drive will be switched on with all values which were valid before.

### M02 Main Program End

M02 works like M30.

### M03 Milling Spindle ON Clockwise

The spindle will be switched on provided that a cutting speed has been programmed, the machine doors are closed and a workpiece is correctly clamped. M03 must be used for all right hand cutting tools.

### M04 Milling Spindle ON Counterclockwise

The same conditions as described under M03 apply here.

M04 must be used for all left hand cutting tools.

### M05 Milling Spindle OFF

The main drive is braked electrically. At the program end the milling spindle is automatically switched off.

### M06 Tool Change

Only for machines with tool turret.

The previously with the T word selected tool will be swivelled in.

The T word describes the tool turret station number.

Example:

```
N100 T04 M06
```

```
N110 G43 H4
```

In the block 100 the tool will be selected by T04 and swivelled in with M06. In the block 110 the length of the tool (entered in H4) will be considered for all following traverse movements (tool length compensation).

After that the main drive will be switched on with all values which were valid before.

### M08 Coolant ON

Only for EMCO PC Mill 100/125/155.

The coolant will be switched on.

### M09 Coolant OFF

Only for EMCO PC Mill 100/125/155.

The coolant will be switched off.

### M27 Swivel Dividing Head

Only for accessory dividing head.

The dividing head will be swivelled for one step (step angle mechanically adjusted).

### M30 Main Program End

With M30 all drives will be switched off and the control will be reset to program start.

### M71 Puff blowing ON

Only for accessory puff blowing device.

The puff blowing device will be switched on.

### M72 Puff blowing OFF

Only for accessory puff blowing device.

The puff blowing device will be switched off.

## M98 Subprogram Call


### Format

N... M98 P...

P ..... The first four digits from the right determine the subprogram number, the other digits the number of repetitions.

### Notes

- M98 can be designated in the same block as the movement command (e.g. G01 X25 M98 P1235001)
- When the count of repetitions is not specified, the subprogram is called once (M98 P5001)
- When the programmed subroutine does not exist an alarm occurs.
- A two loop subprogram call can be executed.



Sequence of program run

## M99 Subprogram End, Jump Instruction

### Format

N... M99 P...

### M99 in the main program

Without jumping address:  
Jump to the program start.  
With jumping address Pxxxx:  
Jump on block no. xxxx

### M99 in the subprogram

Without jumping address:  
Jump to the calling up program, on the next block after the calling up block (see drawing).  
With jumping address Pxxxx:  
Jump to the calling up program on block no. xxxx

### Note

M99 must be the last command in the subprogram.

## G: Flexible NC programming

Variable number	Variable type	Function
#0	Always zero system variable	This variable has always the value zero. Not changeable
#1-33	Local variable	At disposal for calculations in the program
#100-149	Global variables	At disposal for calculations in the program
#500-531	System variable	At disposal for calculations in the program
#1000	System variable	Loading magazine: bar end reached
#1001	System variable	Loading magazine: loader has advanced
#1002	System variable	Loading magazine: first part after bar change
#3901	System variable	Nominal piece number
#3901	System variable	Actual piece number

### Variables and arithmetic parameters

By using variables instead of fixed values, a program can be configured more flexibly. Thus, you can react to signals, such as e.g. measuring values, or the same program can be used for different geometries by using variables as nominal value.

Together with variable calculation and program jumps you get the possibility to create a highly-flexible program archive and thus save programming time.

Local and global variables can be read and written. All other variables can only be read.

Local variables can only be used in that macro in which they are defined.

Global variables can be used in every macro irrespective of the macro in which they were defined.

### Calculating with variables

With the four basic arithmetic operations the usual mathematic notation is valid.

The term at the operator's right can contain constants and/or variables combined by functions.

Each variable can be replaced again by an arithmetic term in square brackets or by a constant.

Example

```
#1=#[#2]
```

During the calculation the limitation is valid that the execution of the calculation is carried out from left to right without observance of the calculation rule point before line.

Example

```
#1=#2*3+#5/2
```

Function	Example
=	#1=2
+	#1=#2+#3
-	#1=#2-#3
*	#1=#2*#3
/	#1=#2/#3

## Control structures

In programs the control sequence can be changed by IF and GOTO instructions. Three types of branchings are possible:

- IF[<condition>] THEN
- IF[<condition>] GOTO <n>
- GOTO <destination>

### IF[<Condition>] THEN

After IF a provisory term must be indicated. If the provisory term applies, a determined macro instruction is carried out. Only one macro instruction can be carried out.

#### Example

With equal values of #1 and #2 the value 5 is allocated to #3.

```
IF [#1 EQ #2] THEN#3=5
```

### IF[<Condition>] GOTO <n>

After IF a provisory term must be indicated. If the provisory term applies, the branching is carried out to block number n. Otherwise the subsequent block is carried out.

#### Example

If the value of the variable #1 is greater than 10, the branching is carried out to block number N4. Otherwise the subsequent block is carried out.

```
IF [#1 GT 10] GOTO 4
```

### GOTO <n>

The jump command GOTO can also be programmed without condition. A variable or constant can be used as a branch destination. With a variable the number can be replaced again by a calculation term in square brackets.

#### Example

Jump to block number 3

```
GOTO 3
```

#### Example

Jump to variable #6

```
GOTO#6
```

## Relational operators

Relational operators consist of two letters and are used to determine, in comparison with two values, if these are equal or if one value is greater and/or less than the other.

Operator	Meaning
EQ	Equal (=)
NE	Unequal (≠)
GT	Greater than (>)
GE	Greater than or equal (≥)
LT	Less than (<)
LE	Less than or equal (≤)

The expressions to be compared can be variable n or constants. A variable can be replaced again by a calculation term in square brackets.

#### Example

```
IF[#12 EQ 1] GOTO10
```

### Comprising macro programming examples:

```
IF[#1000 EQ 1] GOTO10
```

```
IF[#10] NE #0] GOTO#[#1]
```

```
IF[1 EQ 1] THEN#2 =5
```

```
IF#[#4+#[#2/2]] GT #20] THEN#[#10]] =#1*5+#7
```

## H: Alarms and Messages

### Missing digitizer calibration

Cause: A digitizer tablet has been installed but not calibrated

Remedy: Calibrate digitizer tablet (set corner points), see External Input Devices

### 6: CONVERTER ALREADY INITIALIZED

System error. Re-install the software.

### 7: MISSING SETUP CALL

System error. Re-install the software.

### 8: SETUP OF PROGRAM CONTROLLING FAILS

System error. Re-install the software.

### 9: PARSER SETUP FAILS

System error. Re-install the software.

### 10: REGISTRY SETUP FAILS

System error. Re-install the software.

### 11: SETUP OF WORKING POINTS FAILS

System error. Re-install the software.

### 12: SETUP OF WORKING OBJECTS FAILS

System error. Re-install the software.

### 13: SETUP OF COMMAND LIST FAILS

System error. Re-install the software.

### 14: SETUP OF START CONDITION FAILS

System error. Re-install the software.

### 15: SETUP OF EXPORT VARIABLE FAILS

System error. Re-install the software.

### 16: SETUP OF MAIN VARIABLE FAILS

System error. Re-install the software.

### 17: WAITING FOR AC INITIALIZATION

System error. Re-install the software.

### 18: SETUP OF AC FAILS

System error. Re-install the software.

### 19: INVALID SWITCHTONEXTBLOCK ID

System error. Re-install the software.

### 20: NO PROGRAM

System error. Re-install the software.

### 21: PROGRAM NOT FOUND

System error. Re-install the software.

### 1000: PARSER - ERROR OT\_FIRST

System error. Re-install the software.

### 1001: MARKING OF HEADER LINE NOT FOUND

System error. Re-install the software.

### 1002: MARKING OF MAIN PROGRAM NOT FOUND

System error. Re-install the software.

### 1005: INVALID LINE NUMBER

System error. Re-install the software.

### 1006: NO END OF FUNCTION FOUND

System error. Re-install the software.

### 1007: MODUL NAME ALREADY EXISTS

System error. Re-install the software.

### 1009: INVALID MODUL NAME

System error. Re-install the software.

### 1010: NO LINE NUMBER

System error. Re-install the software.

### 1018: WAIT FOR F OR S COMMAND

NC programming error. G4 was programmed without S or F address.

### 1020: NO MORE COMMANDS ALLOWED

NC programming error. G96 must be the only G command in a block.

### 1035: NO OR INVALID PARAMETER

System error. Re-install the software.

### 2016: INVALID S VALUE

NC programming error. Spindle index invalid. Allowed indexes are S[0] and S[1].

## Input Device Alarms 3000 - 3999

These Alarms will be triggered by the control keyboard or digitizer.

### Missing digitizer calibration

Cause: A digitizer tablet has been installed but not calibrated

Remedy: Calibrate digitizer tablet (set corner points), see External Input Devices

### 3001 General RS232 communication error

Remedy: Correct settings of serial interface.

### 3002 Control keyboard missing

Remedy: Connect control keyboard, switch on, ...

### 3003 Digitizer missing

Remedy: Connect digitizer, switch on, ...

### 3004 Check sum error in control keyboard

The keyboard tries an automatic re-initializing - when failed switch off / on keyboard.

### 3005 Error in control keyboard

The keyboard tries an automatic re-initializing - when failed switch off / on keyboard.

### 3006 Error with initializing control keyboard

The keyboard tries an automatic re-initializing - when failed switch off / on keyboard.



## Machine Alarms 6000 - 7999

These alarms will be triggered by the machines. There are different alarms for the different machines. The alarms 6000 - 6999 normally must be confirmed with RESET. The alarms 7000 - 7999 are messages which normally will disappear when the releasing situation is finished.

### PC MILL 50 / 55, PC TURN 50 / 55

The following alarms are valid for the turning and milling machines of the series 50 / 55.

**6000: EMERGENCY OFF**

The EMERGENCY OFF key was pressed. Remove the endangering situation and restart machine and software.

**6001: CYCLE TIME EXCEEDS LIMIT**

Contact EMCO Service.

**6002: NO PLC PROGRAM LOADED**

Contact EMCO Service.

**6003: DB NOT EXISTENT**

Contact EMCO Service.

**6004: RAM ERROR ON PLC BOARD**

Contact EMCO Service.

**6009: FAILURE SAFETY CIRCUIT**

Defective door limit switch or main contactor. Operating the machine is not possible.

Contact EMCO Service.

**6010: X-AXIS NOT READY**

Step motor board defective, 24 V or 30 V fuse defective. Check fuses and switch box fan filter.

Contact EMCO Service.

**6011: Y-AXIS NOT READY**

see alarm 6010.

**6012: Z-AXIS NOT READY**

see alarm 6010.

**6013: MAIN DRIVE NOT READY**

Main drive power supply defective, cable defective, main drive overload.

Check fuse, reduce load.

Contact EMCO service.

**6014: NO SPEED FOR MAIN SPINDLE**

This will be released, when the spindle speed is lower than 20 rpm because of overload.

Alter cutting data (feed, infeed, spindle speed).

**6019: VICE TIMEOUT**

24 V fuse defective, hardware defective.

Contact EMCO service.

**6020: VICE FAILURE**

24 V fuse defective, hardware defective.

Contact EMCO service.

**6024: DOOR NOT CLOSED**

The door was opened while a machine movement.

The program will be aborted.

**6025: GEARBOX COVER NOT CLOSED**

The gearbox cover was opened while a machine movement. A running CNC program will be aborted.

Close the cover to continue.

**6027: DOOR LIMIT SWITCH DEFECTIVE**

The limit switch of the automatic door is displaced, defective, wrong cabled.

Contact EMCO service.

**6028: DOOR TIMEOUT**

The automatic door sticks, the pressured air supply is insufficient, the limit switch is displaced.

Check door, pressured air supply, limit switch or contact EMCO service.

**6030: NO PART CLAMPED**

No workpiece inserted, vice cheek displaced, control cam displaced, hardware defective.  
Adjust or contact EMCO service.

**6031: QUILL FAILURE****6037: CHUCK TIMEOUT****6039: CHUCK PRESSURE FAILURE****6041: TOOL CHANGE TIMEOUT**

Tool turret sticks (collision?), 24 V fuse defective, hardware defective.

A running CNC program will be stopped.

Check for a collision or contact EMCO service.

**6042: TOOL CHANGE TIMEOUT**

see alarm 6041.

**6043: TOOL CHANGE TIMEOUT**

see alarm 6041.

**6044: TOOL TURRET SYNC ERROR**

Hardware defective.

Contact EMCO service.

**6046: TOOL TURRET SYNC MISSING**

Hardware defective.

Contact EMCO service.

**6048: DIVIDING TIME EXCEEDED**

Dividing head sticks, insufficient pressured air supply, hardware defective.

Check for collision, check pressured air supply or contact EMCO service.

**6049: INTERLOCKING TIME EXCEEDED**

see alarm 6048

**6050: FAILURE DIVIDING DEVICE**

Hardware defective.

Contact EMCO service.

**7000: INVALID TOOL NUMBER**

The CNC program will be stopped.

Interrupt program with RESET and correct the program.

**7007: FEED HOLD**

In the robotic mode a HIGH signal is at input E3.7. Feed Stop is active until a low signal is at E3.7.

**7017: GO FOR REFERENCE POINT**

Approach the reference point.

**7040: DOOR OPEN**

The main drive can not be switched on and NC-Start can not be activated.

Some accessories can be operated only with open machine door.

Close the machine to run a program.

**7043: PIECE COUNT REACHED**

A predetermined number of program runs was reached. NC-Start is locked. Reset the counter to continue.

**7050: NO PART CLAMPED**

After switching on or after an the vice is neither at the open position nor at the closed position.

NC-Start is locked.

Traverse the vice manually on a valid end position.

**7051: DIVIDING DEVICE NOT INTERLOCKED**

After switching on or after an the dividing head is not in a lock position. NC-Start is locked.

**PC MILL 100/105/125/155**

The following alarms are valid for the milling machines PC MILL 100/105/125/155.

**6000: EMERGENCY OFF**

The EMERGENCY OFF key was pressed. Remove the endangering situation and restart machine and software.

**6001: PLC-CYCLE TIME EXCEEDING**

Contact EMCO Service.

**6002: PLC - NO PROGRAM CHARGED**

Contact EMCO Service.

**6003: PLC - NO DATA UNIT**

Contact EMCO Service.

**6004: PLC - RAM MEMORY FAILURE**

Contact EMCO Service.

**6005: OVERHEAT BRAKEMODUL**

Main drive was braked too often, large changes of speed within a short time. E4.2 active

**6006: OVERLOAD BRAKE RESISTOR**

see 6005

**6007: SAFETY CIRCUIT FAULT**

Axis and main drive contactor with machine switched off not disabled. Contactor got stuck or contact error. E4.7 was not active during switch-on.

**6009: SAFETY CIRCUIT FAULT**

Defective step motor system.

A running CNC program will be interrupted, the auxiliary drives will be stopped, the reference position will be lost.

Contact EMCO Service.

**6010: DRIVE X-AXIS NOT READY**

The step motor board is defective or too hot, a fuse or cabling is defective.

A running program will be stopped, the auxiliary drives will be switched off, the reference position will be lost.

Check fuses or contact EMCO service.

**6011: DRIVE Y-AXIS NOT READY**

see alarm 6010.

**6012: DRIVE Z-AXIS NOT READY**

see alarm 6010.

**6013: MAIN DRIVE NOT READY**

Main drive power supply defective, main drive too hot, fuse defective.

A running program will be stopped, the auxiliary drives will be switched off.

Check fuses or contact EMCO Service.

**6014: NO MAIN SPINDLE SPEED**

This will be released, when the spindle speed is lower than 20 rpm because of overload.

Alter cutting data (feed, infeed, spindle speed).

The CNC program will be aborted, the auxiliary drives will be stopped.

**6024: MACHINE DOOR OPEN**

The door was opened while a machine movement. The program will be aborted.

**6040: TOOL TURRET INDEX FAILURE**

After WZW procedure drum pressed down by Z-axis. Spindle position wrong or mechanical defect. E4.3=0 in lower state

**6041: TOOL CHANGE TIMEOUT**

Tool drum stuck (collision?), main drive not ready, fuse defective, hardware defective.

A running CNC program will be stopped.

Check for collisions, check fuses or contact EMCO service.

**6043-6046: TOOL DISK POSITION FAULT**

Position error of main drive, error of position supervising (inductive proximity switch defective or disadjusted, drum allowance), fuse defective, hardware defective.

The Z axis could have been slipped out of the toothing while the machine was switched off.

A running CNC program will be stopped.

Contact EMCO service.

**6047: TOOL DISK UNLOCKED**

Tool drum turned out of locked position, inductive proximity switch defective or disadjusted, fuse defective, hardware defective.

A running CNC program will be interrupted.  
Contact EMCO service.

When the tool drum is turned out of locked position (no defect), act as following:

Turn the drum into locking position manually  
Change into MANUAL (JOG) mode.

Turn the key switch. Traverse the Z slide upwards, until the alarm disappears.

**6050: M25 AT RUNNING MAIN SPINDLE**

Cause: Programming mistake in NC program.

A running program will be aborted.

The auxiliary drives will be switched off.

Remedy: Correct NC program

**6064: DOOR AUTOMATIC NOT READY**

Cause: pressure failure automatic door  
automatic door sticks mechanically  
limit switch for open end position defective  
security print circuits defect  
cabling defective  
fuses defective

A running program will be aborted.

The auxiliary drives will be switched off.

Remedy: service automatic door

**6069: CLAMPING FOR TANI NOT OPEN**

When opening the clamping pressure switch does not fall within 400ms. Pressure switch defective or mechanical problem. E22.3

**6070: PRESSURE SWITCH FOR TANI MISSING**

When closing the clamping pressure switch does not respond. No compressed air or mechanical problem. E22.3

**6071: DIVIDING DEVICE NOT READY**

Servo Ready Signal from frequency converter missing. Excess temperature drive TANI or frequency converter not ready for operation.

**6072: VICE NOT READY**

Attempt to start the spindle with an open vice or without clamped workpiece.

Vice sticks mechanically, insufficient compressed air supply, compressed air switch defective, fuse defective, hardware defective.

Check the fuses or contact EMCO service.

**6073: DIVIDING DEVICE NOT READY**

Cause: locking switch defective  
cabling defective  
fuses defective

A running program will be aborted.

The auxiliary drives will be switched off.

Remedy: service automatic dividing device  
lock the dividing device

**6074: DIVIDING TIME EXCEEDED**

Cause: dividing device sticks mechanically  
locking switch defective  
cabling defective  
fuses defective

A running program will be aborted.

The auxiliary drives will be switched off.

Remedy: service automatic dividing device

**6075: M27 AT RUNNING MAIN SPINDLE**

Cause: Programming mistake in NC program.

A running program will be aborted.

The auxiliary drives will be switched off.

Remedy: Correct NC program

**7000: INVALID TOOL NUMBER PROGRAMMED**

The tool position was programmed larger than 10.

The CNC program will be stopped.

Interrupt program with RESET and correct the program.

**7016: SWITCH ON AUXILIARY DRIVES**

The auxiliary drives are off. Press the AUX ON key for at least 0.5 sec. (to avoid accidentally switching on) to switch on the auxiliary drives.

**7017: REFERENCE MACHINE**

Approach the reference point.

When the reference point is not active, manual movements are possible only with key switch at position "setting operation".

**7018: TURN KEY SWITCH**

With NC-Start the key switch was in position "setting operation".

NC-Start is locked.

Turn the key switch in the position "automatic" to run a program.

**7020: SPECIAL OPERATION MODE ACTIVE**

Special operation mode: The machine door is opened, the auxiliary drives are switched on, the key switch is in position "setting operation" and the consent key is pressed.

Manual traversing the axes is possible with open door. Swivelling the tool turret is not possible with open door. Running a CNC program is possible only with standing spindle (DRYRUN) and SINGLE block operation.

For safety: If the consent key is pressed for more than 40 sec. the function of this key is interrupted, the consent key must be released and pressed again.

**7021: INITIALIZE TOOL TURRET**

The tool turret operating was interrupted.

No traversing operation is possible.

Press tool turret key in JOG operation. Message occurs after alarm 6040.

**7022: INITIALIZE TOOL TURRET !**

see 7021

**7038: LUBRICATION SYSTEM FAULT**

The pressure switch is defective or gagged.

NC-Start is locked. This can be reset only by switching off and on the machine.

Contact EMCO service.

**7039: LUBRICATION SYSTEM FAULT**

Not enough lubricant, the pressure switch is defective.

NC-Start is locked.

Check the lubricant and lubricate manually or contact EMCO service.

**7040: MACHINE DOOR OPEN**

The main drive can not be switched on and NC-Start can not be activated (except special operation mode)

Close the machine to run a program.

**7042: INITIALIZE MACHINE DOOR**

Every movement and NC-Start are locked.

Open and close the machine door to initialize the safety circuits.

**7043: PIECE COUNT REACHED**

A predetermined number of program runs was reached. NC-Start is locked. Reset the counter to continue.

**7054: VICE OPEN**

Cause: the workpiece is not clamped

When switching on the main spindle with M3/M4 alarm 6073 (vice not ready) will be released.

Remedy: Clamp

**7055: DIVIDING DEVICE NOT LOCKED**

Cause: the dividing device is not locked

When switching on the main spindle with M3/M4 alarm 6073 (dividing device not ready) will be released.

Remedy: lock dividing device

**7270: OFFSET COMPENSATION ACTIVE !**

Only with PC-MILL 105

Offset compensation activated by the following operation sequence.

- Reference point not active
- Machine in reference mode
- Key switch in manual operation
- Press STRG (or CTRL) and simultaneously 4

This must be carried out if prior to the tool change procedure spindle positioning is not completed (tolerance window too large)

**7271: COMPENSATION FINISHED, DATA SAVED !**

see 7270

**PC TURN 105/120/125/155**

The following alarms are valid for the lathes  
PC TURN 105/120/125/155.

**6000: EMERGENCY OFF**

The EMERGENCY OFF key was pressed.  
The reference position will be lost, the auxiliary drives will be switched off.  
Remove the endangering situation and restart machine and software.

**6001: PLC-CYCLE TIME EXCEEDING**

The auxiliary drives will be switched off.  
Contact EMCO Service.

**6002: PLC - NO PROGRAM CHARGED**

The auxiliary drives will be switched off.  
Contact EMCO Service.

**6003: PLC - NO DATA UNIT**

The auxiliary drives will be switched off.  
Contact EMCO Service.

**6004: PLC - RAM MEMORY FAILURE**

The auxiliary drives will be switched off.  
Contact EMCO Service.

**6008: MISSING CAN SUBSCRIBER**

Check fuses or contact EMCO Service.

**6009: SAFETY CIRCUIT FAULT**

Defective step motor system.  
A running CNC program will be interrupted, the auxiliary drives will be stopped, the reference position will be lost.  
Contact EMCO Service.

**6010: DRIVE X-AXIS NOT READY**

The step motor board is defective or too hot, a fuse is defective, over- or undervoltage from mains.  
A running program will be stopped, the auxiliary drives will be switched off, the reference position will be lost.  
Check fuses or contact EMCO service.

**6012: DRIVE Z-AXIS NOT READY**

see 6010.

**6013: MAIN DRIVE NOT READY**

Main drive power supply defective or main drive too hot, fuse defective, over- or undervoltage from mains.  
A running program will be stopped, the auxiliary drives will be switched off.  
Check fuses or contact EMCO Service.

**6014: NO MAIN SPINDLE SPEED**

This alarm will be released, when the spindle speed is lower than 20 rpm because of overload.  
Alter cutting data (feed, infeed, spindle speed).  
The CNC program will be aborted, the auxiliary drives will be switched off.

**6015: NO DRIVEN TOOL SPINDLE SPEED**

see 6014.

**6024: MACHINE DOOR OPEN**

The door was opened while a machine movement.  
The program will be aborted.

**6040: TOOL TURRET INDEX FAILURE**

The tool turret is in no locked position, tool turret sensor board defective, cabling defective, fuse defective.  
A running CNC program will be stopped.  
Swivel the tool turret with the tool turret key, check fuses or contact EMCO service.

**6041: TOOL CHANGE TIMEOUT**

Tool drum stuck (collision?), fuse defective, hardware defective.  
A running CNC program will be stopped.  
Check for collisions, check fuses or contact EMCO service.

**6042: TOOL TURRET OVERHEAT**

Tool turret motor too hot.  
With the tool turret a max. of 14 swivel procedures a minute may be carried out.

**6043: TOOL CHANGE TIMEOUT**

Tool drum sticks (collision?), fuse defective, hardware defective.  
A running CNC program will be stopped.  
Check for collisions, check fuses or contact EMCO service.

**6046: TOOL TURRET ENCODER FAULT**

Fuse defective, hardware defective.  
Check fuses or contact EMCO service.

**6048: CHUCK NOT READY**

Attempt to start the spindle with open chuck or without clamped workpiece.  
Chuck sticks mechanically, insufficient pressured air supply, fuse defective, hardware defective.  
Check fuses or contact EMCO service.

**6049: COLLET NOT READY**

see 6048

**6050: M25 DURING SPINDLE ROTATION**

With M25 the main spindle must stand still (consider run-out time, evtl. program a dwell)

**6055: NO PART CLAMPED**

This alarm occurs when with rotating spindle the clamping device or the tailstock reach the end position. The workpiece has been pushed out of the chuck or has been pushed into the chuck by the tailstock.  
Check clamping device settings, clamping forces, alter cutting data.

**6056: QUILL NOT READY**

Attempt to start the spindle or to move an axis or to swivel the tool turret with undefined tailstock position. Tailstock is locked mechanically (collision), insufficient pressured air supply, fuse defective, magnetic switch defective.  
Check for collisions, check fuses or contact EMCO service.

**6057: M20/M21 DURING SPINDLE ROTATION**

With M20/M21 the main spindle must stand still (consider run-out time, evtl. program a dwell)

**6058: M25/M26 DURING QUILL FORWARD**

To actuate the clamping device in an NC program with M25 or M26 the tailstock must be in back end position.

**6059: C-AXIS SWING IN TIMEOUT**

C-axis does not swivel in within 4 seconds.  
Reason: not sufficient air pressure, and/or mechanics stuck.

**6060: C-AXIS INDEX FAILURE**

When swivelling in the C-axis the limit switch does not respond.  
Check pneumatics, mechanics and limit switch.

**6064: AUTOMATIC DOOR NOT READY**

Door sticks mechanically (collision), insufficient pressured air supply, limit switch defective, fuse defective.  
Check for collisions, check fuses or contact EMCO service.

**6065: LOADER MAGAZINE FAILURE**

Loader not ready.  
Check if the loader is switched on, correctly connected and ready for operation and/or disable loader (WinConfig).

**6066: CLAMPING DEVICE FAILURE**

No compressed air at the clamping device  
Check pneumatics and position of the clamping device proximity detectors.

**7000: INVALID TOOL NUMBER PROGRAMMED**

The tool position was programmed larger than 8.  
The CNC program will be stopped.  
Interrupt program with RESET and correct the program.

**7016: SWITCH ON AUXILIARY DRIVES**

The auxiliary drives are off. Press the AUX ON key for at least 0.5 sec. (to avoid accidentally switching on) to switch on the auxiliary drives (also a lubricating pulse will be released).

**7017: REFERENCE MACHINE**

Approach the reference point.  
When the reference point is not active, manual movements are possible only with key switch at position "setting operation".

**7018: TURN KEY SWITCH**

With NC-Start the key switch was in position "setting operation".

NC-Start is locked.

Turn the key switch in the position "automatic" to run a program.

**7019: PNEUMATIC LUBRICATION MONITORING!**

Refill pneumatic oil

**7020: SPECIAL OPERATION MODE ACTIVE**

Special operation mode: The machine door is opened, the auxiliary drives are switched on, the key switch is in position "setting operation" and the consent key is pressed.

Manual traversing the axes is possible with open door. Swivelling the tool turret is possible with open door. Running a CNC program is possible only with standing spindle (DRYRUN) and SINGLE block operation.

For safety: If the consent key is pressed for more than 40 sec. the function of this key is interrupted, the consent key must be released and pressed again.

**7021: TOOL TURRET NOT LOCKED**

The tool turret operating was interrupted.

NC start and spindle start are locked. Press the tool turret key in the RESET status of the control.

**7038: LUBRICATION SYSTEM FAULT**

The pressure switch is defective or gagged.

NC-Start is locked. This alarm can be reset only by switching off and on the machine.

Contact EMCO service.

**7039: LUBRICATION SYSTEM FAULT**

Not enough lubricant, the pressure switch is defective.

NC-Start is locked.

Check the lubricant and lubricate manually or contact EMCO service.

**7040: MACHINE DOOR OPEN**

The main drive can not be switched on and NC-Start can not be activated (except special operation mode)

Close the machine to run a program.

**7042: INITIALIZE MACHINE DOOR**

Every movement and NC-Start are locked.

Open and close the machine door to initialize the safety circuits.

**7043: PIECE COUNT REACHED**

A predetermined number of program runs was reached. NC-Start is locked. Reset the counter to continue.

**7048: CHUCK OPEN**

This message shows that the chuck is open. It will disappear if a workpiece will be clamped.

**7049: CHUCK - NO PART CLAMPED**

No part is clamped, the spindle can not be switched on.

**7050: COLLET OPEN**

This message shows that the collet is open. It will disappear if a workpiece will be clamped.

**7051: COLLET - NO PART CLAMPED**

No part is clamped, the spindle can not be switched on.

**7052: QUILL IN UNDEFINED POSITION**

The tailstock is in no defined position.

All axis movements, the spindle and the tool turret are locked.

Drive the tailstock in back end position or clamp a workpiece with the tailstock.

**7053: QUILL - NO PART CLAMPED**

The tailstock reached the front end position. Traverse the tailstock back to the back end position to continue.

**7054: NO PART CLAMPED**

No part clamped, switch-on of the spindle is locked.

**7055: CLAMPING DEVICE OPEN**

This message indicates that the clamping device is not in clamping state. It disappears as soon as a part is clamped.



## AC95 ALARMS

### Axis Controller Alarms 8000 - 9999

#### 8000 Fatal Error AC

##### 8004 ORDxx Failure main-drive unit

##### 8005 - 8009 ORDxx Internal error AC

Remedy: report to EMCO if repeatable

##### 8010 ORDxx Syncr. error main drive

Cause: synchronisation mark missing for main drive

Remedy: report to service technician, if repeatable

##### 8011 - 8013 ORDxx Internal error AC

Remedy: report to EMCO, if repeatable

##### 8014 ORDxx Decel.-time of axis too high

Remedy: report to service technician, if repeatable

##### 8018 ORDxx Internal error AC

Remedy: report to EMCO, if repeatable

##### 8021 ORDxx Internal error AC

Remedy: report to EMCO, if repeatable

##### 8022 ORDxx Internal error AC

Remedy: report to EMCO, if repeatable

##### 8023 ORDxx Invalid Z value for helix

Cause: The Z value of the helix must be smaller than the length of the arc to be traversed

Remedy: Program correction

##### 8100 Fatal init error AC

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

##### 8101 Fatal init error AC

see 8101.

##### 8102 Fatal init error AC

see 8101.

##### 8103 Fatal init error AC

see 8101.

##### 8104 Fatal system error AC

see 8101.

##### 8105 Fatal init error AC

see 8101.

##### 8106 No PC-COM card found

Cause: PC-COM board can not be accessed (ev. not mounted).

Remedy: Mount board, adjust other address with jumper

##### 8107 PC-COM card not working

see 8106.

##### 8108 Fatal error on PC-COM card

see 8106.

##### 8109 Fatal error on PC-COM card

see 8106.

##### 8110 PC-COM init message missing

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

##### 8111 Wrong configuration of PC-COM

see 8110.

##### 8113 Invalid data (pccom.hex)

see 8110.

##### 8114 Programming error on PC-COM

see 8110.

##### 8115 PC-COM packet acknowledge missing

see 8110.

##### 8116 PC-COM startup error

see 8110.

##### 8117 Fatal init data error (pccom.hex)

see 8110.

##### 8118 Fatal init error AC

see 8110, ev. insufficient RAM memory

##### 8119 PC interrupt no. not valid

Cause: The PC interrupt number can not be used.

Remedy: Find out free interrupt number in the Windows95 system control (allowed: 5,7,10,11,12,3,4 und 5) and enter this number in WinConfig.

##### 8120 PC interrupt no. unmaskable

see 8119

##### 8121 Invalid command to PC-COM

Cause: Internal error or defective cable

Remedy: Check cables (screw it); Restart software or reinstall when necessary, report to EMCO, if repeatable.

##### 8122 Internal AC mailbox overrun

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

##### 8123 Open error on record file

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

##### 8124 Write error on record file

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

**8125 Invalid memory for record buffer**

Cause: Insufficient RAM, record time exceeding.  
 Remedy: Restart software, ev. remove drivers etc. to gain more RAM, reduce record time.

**8126 AC Interpolation overrun**

Cause: Ev. insufficient computer performance.  
 Remedy: Set a longer interrupt time in WinConfig. This may result in poorer path accuracy.

**8127 Insufficient memory**

Cause: Insufficient RAM  
 Remedy: Close other programs, restart software, ev. remove drivers etc. to gain more RAM.

**8128 Invalid message to AC**

Cause: Internal error  
 Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

**8129 Invalid MSD data - axisconfig.**

see 8128.

**8130 Internal init error AC**

see 8128.

**8130 Internal init error AC**

see 8128.

**8132 Axis accessed by multiple channels**

see 8128.

**8133 Insufficient NC block memory AC**

see 8128.

**8134 Too much center points programmed**

see 8128.

**8135 No centerpoint programmed**

see 8128.

**8136 Circle radius too small**

see 8128.

**8137 Invalid for Helix specified**

Cause: Wrong axis for helix. The combination of linear and circular axes does not match.  
 Remedy: Program correction.

**8140 Maschine (ACIF) not responding**

Cause: Machine off or not connected.  
 Remedy: Switch on machine or connect.

**8141 Internal PC-COM error**

Cause: Internal error  
 Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

**8142 ACIF Program error**

Cause: Internal error  
 Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

**8143 ACIF packet acknowledge missing**  
 see 8142.

**8144 ACIF startup error**  
 see 8142.

**8145 Fatal init data error (acif.hex)**  
 see 8142.

**8146 Multiple request for axis**  
 see 8142.

**8147 Invalid PC-COM state (DPRAM)**  
 see 8142.

**8148 Invalid PC-COM command (CNo)**  
 see 8142.

**8149 Invalid PC-COM command (Len)**  
 see 8142.

**8150 Fatal ACIF error**  
 see 8142.

**8151 AC Init Error (missing RPG file)**  
 see 8142.

**8152 AC Init Error (RPG file format)**  
 see 8142.

**8153 FPGA program timeout on ACIF**  
 see 8142.

**8154 Invalid Command to PC-COM**  
 see 8142.

**8155 Invalid FPGA packet acknowledge**  
 see 8142 or hardware error on ACIF board (contact EMCO Service).

**8156 Sync within 1.5 revol. not found**  
 see 8142 or Bero hardware error (contact EMCO Service).

**8157 Data record done**  
 see 8142.

**8158 Bero width too large (referencing)**  
 see 8142 or Bero hardware error (contact EMCO Service).

**8159 Function not implemented**  
 Bedeutung: In normal operation this function can not be executed

**8160 Axis synchronization lost axis 3..7**  
 Cause: Axis spins or slide is locked, axis synchronisation was lost  
 Remedy: Approach reference point

**8161 X-Axis synchronization lost**  
 Step loss of the step motor. Causes:

- Axis mechanically blocked
- Axis belt defective
- Distance of proximity detector too large (>0,3mm) or proximity detector defective
- Step motor defective

**8162 Y-Axis synchronization lost**

see 8161

**8163 Z-Axis synchronization lost**

see 8161

**8164 Software limit switch max axis 3..7**

Cause: Axis is at traverse area end

Remedy: Retract axis

**8168 Software limit overtravel axis 3..7**

Cause: Axis is at traverse area end

Remedy: Retract axis

**8172 Communication error to machine**

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.  
Check connection PC - machine, eventually eliminate distortion sources.

**8173 INC while NC program is running****8174 INC not allowed****8175 MSD file could not be opened**

Cause: Internal error

Remedy: Restart software oder bei Bedarf neu installieren, report to EMCO, if repeatable.

**8176 PLS file could not be opened**

see 8175.

**8177 PLS file could not be accessed**

see 8175.

**8178 PLS file could not be written**

see 8175.

**8179 ACS file could not be opened**

see 8175.

**8180 ACS file could not be accessed**

see 8175.

**8181 ACS file could not be written**

see 8175.

**8182 Gear change not allowed****8183 Gear too high****8184 Invalid interpolaton command****8185 Forbidden MSD data change**

see 8175.

**8186 MSD file could not be opened**

see 8175.

**8187 PLC program error**

see 8175.

**8188 Gear command invalid**

see 8175.

**8189 Invalid channel assignement**

see 8175.

**8190 Invalid channel within message****8191 Invalid jog feed unit****8192 Invalid axis in command****8193 Fatal PLC error**

see 8175.

**8194 Thread without length****8195 No thread slope in leading axis**

Remedy: Program thread pitch

**8196 Too many axis for thread**

Remedy: Program max. 2 axes for thread.

**8197 Thread not long enough**

Cause: Thread length too short.

With transition from one thread to the other the length of the second thread must be sufficient to produce a correct thread.

Remedy: Longer second thread or replace it by a linear interpolation (G1).

**8198 Internal error (to many threads)**

see 8175.

**8199 Internal error (thread state)**

Cause: Internal error

Remedy: Restart software or reinstall when necessary, report to EMCO, if repeatable.

**8200 Thread without spindle on**

Remedy: Switch on spindle

**8201 Internal thread error (IPO)**

see 8199.

**8201 Internal thread error (IPO)**

see 8199.

**8203 Fatal AC error (0-ptr IPO)**

see 8199.

**8204 Fatal init error: PLC/IPO running**

see 8199.

**8205 PLC Runtime exceeded**

Cause: Insufficient computer performance

**8206 Invalid PLC M-group initialisation**

see 8199.

**8207 Invalid PLC machine data**

see 8199.

**8208 Invalid application message**

see 8199.

**8211 Feed too high (thread)**

Cause: Thread pitch too large / missing, Feed for thread reaches 80% of rapid feed

Remedy: Program correction, lower pitch or lower spindle speed for thread

**8212 Rotation axis not allowed****8213 Circle and rotation axis can't be interpolated****8214 Thread and rotation axis can't be interpolated****8215 Invalid state****8216 No rotation axis for rotation axis switch****8217 Axis type not valid!****8218 Referencing round axis without selected round axis!****8219 Thread not allowed without spindle encoder!****8220 Buffer length exceeded in PC send message!****8221 Spindle release although axis is no spindle!****8222 New master spindle is not valid****8223 Can't change master spindle (no M5)!****8224 Invalid stop mode****8225 Invalid parameter for BC\_MOVE\_TO\_IO!****8226 Rotary axis switch not valid (MSD data)!****8227 Speed setting not allowed while rotary axis is active!****8228 Rotary axis switch not allowed while axis move!****8229 Spindle on not allowed while rotary axis is active!****8230 Program start not allowed due to active spindle rotation axis!****8231 Axis configuration (MSD) for TRANSMIT not valid!****8232 Axis configuration (MSD) for TRACYL not valid!****8233 Axis not available while TRANSMIT/TRACYL is active!****8234 Axis control grant removed by PLC while axis interpolates!****8235 Interpolation invalid while axis control grant is off by PLC!****8236 TRANSMIT/TRACYL activated while axis or spindle moves!****8237 Motion through pole in TRANSMIT!****8238 Speed limit in TRANSMIT exceeded!****8239 DAU exceeded 10V limit!****8240 Function not valid during active transformation (TRANSMIT/TRACYL)!****8241 TRANSMIT not enabled (MSD)!****8242 TRACYL not enabled (MSD)!****8243 Round axis invalid during active transformation!****8245 TRACYL radius = 0!****8246 Offset alignment not valid for this state!****8247 Offset alignment: MSD file write protected!****8248 Cyclic supervision failed!****8249 Axis motion check alarm!****8250 Spindle must be rotation axis !****8251 Lead for G331/G332 missing !****8252 Multiple or no linear axis programmed for G331/G332 !****8253 Speed value for G331/G332 and G96 missing !****8254 Value for thread starting point offset not valid!****8255 Reference point not in valid software limits!****8256 Spindle speed too low while executing G331/G332!**

# I: Control Alarms

## Control Alarms

These alarms can occur only with operating and programming the control functions or with running CNC programs.

- 1 RS232 parity error !**  
Cause: Data transmission error parity error, wrong RS 232 setting in external device  
Remedy: Check data cables, set serial interface of the external device
- 2 RS232 transmission error !**  
Cause: Data transmission error character overflow  
Data transmission error invalid data frame  
Remedy: Check data cables, set serial interface of the external device
- 10 Nxxxx Invalid G-code**  
Remedy: Program correction
- 11 ORDxx Feed wrong/missing**  
Cause: Attempt to start with feed = 0, also with G95/96, if S = 0 or M5  
Remedy: Program correction
- 21 Nxxxx Circle: Wrong plane selected**  
Cause: The wrong plane (G17, 18, 19) is active for a circle  
Remedy: Program correction
- 30 Nxxxx Invalid tool offset number**  
Cause: The lower 2 digits of the T number are too great  
Remedy: Program correction
- 33 Nxxxx CRC can't be determined**  
Cause: Too much blocks without new position programmed, invalid contour element, programmed circle radius smaller than cutter radius, contour element too short.  
Remedy: Program correction
- 34 Nxxxx Error on deactivating CRC**  
Remedy: Program correction
- 37 Nxxxx Plane change while CRC act.**  
Cause: Change of plane not permitted with active cutter radius compensation  
Remedy: Program correction
- 41 Nxxxx Contour violation CRC**  
Cause: Invalid contour element, programmed circle radius smaller than cutter radius, contour element too short, contour violation with full circle.  
Remedy: Program correction
- 51 Nxxxx Wrong chamfer/radius value**  
Cause: The contour elements between a chamfer / radius should be inserted are too short.  
Remedy: Program correction
- 52 Nxxxx Invalid contour draft**  
Cause: From the programmed parameters no valid contour draft would result  
Remedy: Program correction
- 53 Nxxxx Wrong parameter structure**  
Cause: From the programmed parameters no valid contour draft would result, wrong parameter programmed  
Remedy: Program correction
- 56 Nxxxx Wrong angle value**  
Cause: With the programmed angle no intersection point would result  
Remedy: Program correction
- 57 Nxxxx Error in contour draft**  
Cause: Invalid parameters programmed.  
Remedy: Program correction
- 58 Nxxxx Contour draft not determinable**  
Cause: Too much blocks without new position programmed, program end while contour draft  
Remedy: Program correction
- 60 Nxxxx Block number not found**  
Cause: Jump target not found  
Remedy: Program correction
- 62 Nxxxx General cycle error**  
Cause: Call-up counter of subprogram call invalid, feed<=0, thread pitch missing/<=0, cutting depth missing/<=0/invalid, retraction height too small, block address P/Q missing, declaration pattern repetition missing/invalid, infeed for next cut missing/invalid, undercut at cycle ground <0, cycle end point missing/invalid, thread end point missing/invalid;  
Remedy: Program correction
- 63 Nxxxx Wrong Cycle call**  
Cause: P/Q missing, wrong address  
Remedy: Program correction
- 70 Insufficient memory**  
Cause: The PC has not enough memory  
Remedy: Close all other Windows applications, remove resident programs from memory, restart the PC

**71 Program not found**

Cause: NC program not found  
With program start no program was selected  
Remedy: Correct call-up or create program, select program

**73 File already exists !**

Remedy: Select other file name.

**77 Insufficient RAM for subroutine**

Cause: Subprograms interlocked too deep  
Remedy: Program correction

**83 Nxxxx Circle not in active plane**

Cause: Circle is not in active plane for CRC  
Remedy: Program correction

**142 Wrong simulation area**

Cause: Wrong scale factor (e.g. 0) programmed  
Remedy: Program correction

**142 Invalid scale factor**

Cause: No or an invalid simulation area was entered  
Remedy: Enter correct simulation area

**315 ORDxx Rotatory checking X**

Cause: The step motor has fallen out of pace  
Remedy: Reduce infeed and feed, check slides for smooth running, approach reference point

**325 ORDxx Rotatory checking Y**

see alarm 315

**335 ORDxx Rotatory checking Z**

see alarm 315

**500 ORDxx Target point exceeds work.area**

Cause: Target point, circle target point or circle out of working area limitation  
Remedy: Program correction

**501 ORDxx Target point exceeds SW limit**

Cause: Target point, circle target point or circle out of working area limitation  
Remedy: Program correction

**510 ORDxx Software-limit switch X**

Cause: Software limit switch in X exceeded (JOG)  
Remedy: Traverse back manually

**520 ORDxx Software-limit switch Y**

see 510

**530 ORDxx Software-limit switch Z**

see 510

**2501 ORDxx Synchronisation-error AC**

Remedy: RESET, report to EMCO if reproducible

**2502 ORDxx Synchronisation-error AC**

see 2501

**2503 ORDxx Synchronisation-error AC**

see 2501

**2504 ORDxx No memory for interpreter**

Cause: Too less RAM memory, continuing the program is not possible  
Remedy: Close all Windows application, close WinNC, remove resident programs from AUTOEXEC.BAT and CONFIG.SYS, restart the PC

**2505 ORDxx No memory for interpreter**

see 2504

**2506 ORDxx Too less RAM**

see 2504

**2507 ORDxx Reference point not active**

Remedy: Approach reference point

**2508 ORDxx Internal error NC core**

Remedy: RESET, report to EMCO if reproducible

**2520 ORDxx RS485 device absent**

Cause: With program start a RS485 device did not report, while program run a device got defective  
AC Axis controller  
SPS PLC  
MT control keyboard  
Remedy: Switch on RS485 device (machine, control keyboard), check cables and plugs, check terminator plug, report to EMCO if reproducible

**2521 ORDxx RS485 communication error**

Remedy: PC restart, report to EMCO if reproducible

**2522 ORDxx RS485 communication error**

Remedy: PC restart, report to EMCO if reproducible

**2523 ORDxx INIT error on RS485 PC-board**

See "Software Installation", Mistakes with installation of the software

**2524 ORDxx Gen.-Failure RS485 PC-board**

Remedy: PC restart, report to EMCO if reproducible

**2525 ORDxx Transmit error RS485**

Cause: Transmission error by poor plug connections, missing terminator, external sources of electromagnetic interference  
Remedy: Check the error sources above

**2526 ORDxx Transmit error RS485**

see 2525

**2527 ORDxx Internal error AC**

Remedy: Switch machine off/on, report to EMCO if reproducible

**2528 ORDxx Operating system error PLC**

Remedy: Switch machine off/on, report to EMCO if reproducible

**2529 ORDxx External keyboard error**

Remedy: The external keyboard always must be switched on after the PC. Restart the software, report to EMCO if reproducible

**2540 ORDxx Error saving setting-data**

Cause: Hard disk full, wrong path setting, no writing access

Remedy: Check hard disk space, check writing access, reinstallation of the software if reproducible

**2545 ORDxx Drive / Device not ready**

Remedy: Insert disk, lock drive, check disk drive, ...

**2546 ORDxx Checksum error machine-data**

Remedy: Restart, report to EMCO if reproducible

**2550 ORDxx PLC simulation error**

Remedy: Restart, report to EMCO if reproducible

**2551 ORDxx PLC simulation error**

Remedy: Restart, report to EMCO if reproducible

**2562 Read error on CNC program**

Cause: Defective program file, DOS read error (disk, hard disk)

Remedy: Solve problem on DOS level, eventually reinstallation of the software

**2614 ORDxx Internal error MSD**

Remedy: Report to EMCO if reproducible

**2650 ORDxx Internal error cycle call up**

Cause: Invalid cycle call when a cycle was called with a G command

Remedy: Program correction

**2849 Internal error CRC**

Remedy: Report to EMCO if reproducible

**2904 Helix Z value too large**

Cause: The pitch of the helix must not be larger than 45°

Remedy: Program correction

